

AgGPS™ 124 / 132

Operation Manual

Part Number: 38747-00

Revision: A

Date: February 1999

*Trimble Navigation Limited
645 North Mary Avenue
Post Office Box 3642
Sunnyvale, CA 94088-3642
U.S.A.
+1-800-827-8000 in North America
+1-408-481-8000 International
FAX: +1-408-481-7744
www.trimble.com*

*Trimble
Precision Agricultural Systems
9290 Bond Street, Suite 102
Overland Park, KS 66214
U.S.A.
+1-800-865-7438 in North America
+1-913-495-2700 International
FAX: +1-913-495-2750
Trimble Navigation Europe Limited*

*Trimble House, Meridian Office Park
Osborn Way, Hook
Hampshire RG27 9HX
ENGLAND
+44-1256-760-150
FAX: +44-1256-760-148*

*Trimble Navigation Singapore PTE Limited
79 Anson Road
#05-02
Singapore 079906
SINGAPORE
+65-325-5668
FAX: +65-225-9989*

*Trimble Japan K.K.
Sumitomo Hamamatsu-cho, Building 10F
1-18-16 Hamamatsu-cho Minato-ku
Tokyo 105
JAPAN
+81-3-5472-0880
FAX: +81-3-5472-2326*

*Trimble Navigation New Zealand Limited
11 Birmingham Drive
P.O. Box 8729 Riccarton
Christchurch
NEW ZEALAND
+64-3-339-1400
FAX: +64-3-339-1417*

Copyrights

© 1999 Trimble Navigation Limited. All rights reserved. No part of this manual may be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form without prior written consent from Trimble Navigation Limited.

Printed in the United States of America. Printed on recycled paper.

Release Notice

This is the February 1999 release (Revision A) of the *AgGPS 124/132 Operation Manual*, part number 38747-00.

Trademarks

Trimble and the Trimble logo are trademarks of Trimble Navigation Limited, registered in the United States and other countries.

AgGPS, The Choice, and TSIP are trademarks of Trimble Navigation Limited.

Microsoft, MS-DOS, Windows, Windows 95, and Windows NT are registered trademarks or trademarks of Microsoft Corporation. LandStar is a trademark and a service mark of Racal NCS, Inc. Intel is a trademark of Intel Corporation. All other brand names are trademarks of their respective holders.

Disclaimer of Warranty

EXCEPT AS INDICATED IN "LIMITED WARRANTY" HEREIN, TRIMBLE HARDWARE, SOFTWARE, FIRMWARE AND DOCUMENTATION IS PROVIDED "AS IS" AND WITHOUT EXPRESS OR LIMITED WARRANTY OF ANY KIND BY EITHER TRIMBLE NAVIGATION LIMITED OR ANYONE WHO HAS BEEN INVOLVED IN ITS CREATION, PRODUCTION, OR DISTRIBUTION INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK, AS TO THE QUALITY AND PERFORMANCE OF THE TRIMBLE HARDWARE, SOFTWARE, FIRMWARE AND DOCUMENTATION, IS WITH YOU. SOME STATES DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES, SO THE ABOVE EXCLUSION MAY NOT APPLY TO YOU.

Limitation of Liability

IN NO EVENT WILL TRIMBLE NAVIGATION LIMITED OR ANY PERSON INVOLVED IN THE CREATION, PRODUCTION, OR DISTRIBUTION OF THE TRIMBLE SOFTWARE BE LIABLE TO YOU ON ACCOUNT OF ANY CLAIM FOR ANY DAMAGES, INCLUDING ANY LOST PROFITS, LOST SAVINGS, OR OTHER SPECIAL, INCIDENTAL, CONSEQUENTIAL, OR EXEMPLARY DAMAGES, INCLUDING BUT NOT LIMITED TO ANY DAMAGES ASSESSED AGAINST OR PAID BY YOU TO ANY THIRD PARTY, ARISING OUT OF THE USE, LIABILITY TO USE, QUALITY OR PERFORMANCE OF SUCH TRIMBLE SOFTWARE AND DOCUMENTATION, EVEN IF TRIMBLE NAVIGATION LIMITED OR ANY SUCH PERSON OR ENTITY HAS BEEN ADVISED OF THE POSSIBILITY OF DAMAGES, OR FOR ANY CLAIM BY ANY OTHER PARTY. SOME STATES DO NOT ALLOW THE LIMITATION OR EXCLUSION OF LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES SO, THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.

Software and Firmware Limited Warranty

Trimble Navigation Limited warrants that Software and Firmware products will substantially conform to the published specifications provided it is used with the Trimble products, computer products, and operating system for which it was designed. For a period of ninety (90) days, commencing thirty (30) days after shipment from Trimble, Trimble also warrants that the magnetic media on which Software and Firmware are distributed and the documentation are free from defects in materials and workmanship. During the ninety (90) day warranty period, Trimble will replace defective media or documentation, or correct substantial program errors at no charge. If Trimble is unable to replace defective media or documentation, or correct program errors, Trimble will refund the price paid for The Software. These are your sole remedies for any breach in warranty.

Hardware Limited Warranty

Trimble Navigation Limited products are warranted against defects in material and workmanship for a period of one year. The warranty period shall commence thirty (30) days after shipment from Trimble's factory. Warranty service will be provided at a designated Trimble Service Center. Trimble will at its option either repair or replace products that prove to be defective. The Customer shall pay all shipping charges for products returned to Trimble for warranty service. Trimble shall pay all shipping charges for the return of products to the Customer.

The above warranty shall not apply to defects resulting from:

1. Improper or inadequate maintenance by the buyer
2. Buyer-supplied software or interfacing
3. Unauthorized modification or misuse
4. Operation outside of the environmental specifications of the product
5. Improper installation, where applicable
6. Lightning or other electrical discharge
7. Fresh or salt water immersion or spray
8. Normal wear and tear on consumable parts (for example, batteries)

No other warranty is expressed or implied. Trimble Navigation Limited specifically disclaims the implied warranties of fitness for a particular purpose and merchantability.

Contents

About This Manual

Scope and Audiencexix
Organizationxx
Related Informationxxi
Update Notesxxi
Other Informationxxi
World Wide Web (WWW) Sitexxi
File Transfer Protocol (FTP) Sitexxi
Technical Assistancexxii
Reader Comment Form.xxiii
Document Conventions.xxiii
Warnings, Cautions, Notes, and Tips.xxiv

1 Overview

1.1 Differential GPS Positioning1-3
1.1.1 Sources of GPS Error1-3
1.1.2 DGPS Accuracy1-4
1.2 Measuring GPS Accuracy1-7
1.2.1 Receiving Beacon DGPS1-7
1.2.2 Receiving Satellite DGPS (AgGPS 132 only).1-9
1.3 Standard Features.1-10

1.4	Receiver Enhancements	1-11
1.4.1	Fast Rate (P/N 33176-10)	1-11
1.4.2	Differential Base Station (P/N 33176-30)	1-11
1.4.3	Everest Technology (P/N 33176-40)	1-11
1.5	Application Options	1-12
1.5.1	Parallel Swathing (P/N 34623)	1-12
1.5.2	Ag Field Pack (P/N 32294)	1-12
1.6	Receiver Connections	1-13
1.6.1	ASCII, TSIP, and RTCM Input	1-14
1.6.2	RTCM, TSIP and NMEA Output	1-14
1.6.3	1 PPS Output	1-14

2 Installing the AgGPS Receiver

2.1	Unpacking and Inspecting the Shipment	2-1
2.1.1	Opening the Shipping Carton	2-2
2.1.2	Reporting Shipping Problems	2-4
2.2	Installation Guidelines	2-5
2.2.1	Choosing a Location.	2-5
2.2.2	Considering Environmental Conditions	2-5
2.3	Mounting the Receiver	2-6
2.4	Mounting the Antenna	2-6
2.4.1	Sources of Electrical Interference	2-7
2.5	Routing and Connecting the Antenna Cable	2-8
2.6	Connecting External Devices.	2-9
2.6.1	Connecting the Standard Data/Power Cable (P/N 30945)	2-10
2.6.2	Connecting the Optional CASE AFS Power/Data Cable (P/N 32609)	2-12
2.6.3	Connecting the Optional John Deere GreenStar Data Cable (P/N 34189)	2-13

2.6.4	Connecting the Optional Ag Leader Power/Data Cable (P/N 30660)2-15
2.6.5	Connecting the Optional Power/Data RTCM/NMEA Cable (P/N 32015)2-16
2.6.6	Connecting the Optional RDS Cable (P/N 35142)2-17
2.6.7	Connecting the Optional Windows CE with Cigarette Power Adapter Cable (P/N 35283)2-18
2.6.8	Connecting the Optional Windows CE Cable (P/N 30661)2-18

3 Getting Started

3.1	Using the Front Panel.3-1
3.1.1	Viewing Status Screens3-3
3.2	The Home Screen.3-5
3.2.1	Beacon and Satellite Mode Home Screens3-6
3.3	Below Home Screen Configurables3-11
3.3.1	Contrast3-11
3.3.2	Units3-12
3.3.3	Configuration Lockout Screen.3-13
3.3.4	Language Screen.3-14

4 Operation Screens

4.1	Utility Screens4-2
4.1.1	Area Calculation.4-3
4.1.2	Adjusted Area4-4
4.1.3	Path Length4-5
4.1.4	Perimeter.4-5
4.1.5	Segment Length4-5

5 Status

5.1	GPS Status Screens5-3
5.1.1	Location5-4
5.1.2	Altitude5-5
5.1.3	Velocity5-6
5.1.4	GPS Satellite Information5-7
5.1.5	DOPs.5-9
5.2	Beacon DGPS Status (Beacon Mode Only)5-10
5.2.1	Beacon Status5-11
5.2.2	Alternate Beacon5-12
5.2.3	DGPS Data Source5-13
5.2.4	DGPS Age5-14
5.3	Satellite DGPS Status (AgGPS 132 in Satellite Mode Only).5-15
5.3.1	Satellite Differential Status5-16
5.3.2	Service Provider ID5-17
5.3.3	DGPS Data Source5-18
5.3.4	DGPS Age5-19
5.3.5	Racal-LandStar Service Info5-20
5.3.6	OmniSTAR Service Info.5-21
5.3.7	Service ID and Initialization Vector (IV)5-22
5.4	Receiver Status5-23
5.4.1	Time Screen5-23
5.4.2	Date and GPS Week5-24
5.4.3	Receiver Serial Number5-25
5.4.4	Firmware Version and Release Date.5-26
5.4.5	Receiver Options.5-27
5.4.6	System Voltages5-28
5.4.7	Incident Report5-29
5.5	CAN Status5-29
5.5.1	Channel A Status5-30

5.5.2	Channel B Status	5-31
-------	----------------------------	------

6 Configuring the AgGPS 124 and 132 Receiver

6.1	Configuring the AgGPS Receiver	6-1
6.1.1	Using the Keypad to Change Configuration Settings	6-2
6.2	GPS Configuration	6-3
6.2.1	Restore Defaults	6-3
6.2.2	GPS Mode	6-4
6.2.3	System Masks	6-5
6.2.4	PDOP Settings	6-6
6.2.5	PV Filter and Position Rate	6-7
6.2.6	Dynamic Mode	6-8
6.3	DGPS Configuration	6-8
6.3.1	DGPS Mode	6-9
6.3.2	DGPS Correction Age	6-10
6.3.3	DGPS Source (AgGPS 132 only)	6-10
6.3.4	Beacon Mode	6-11
6.3.5	EZ Beacon 0	6-12
6.3.6	EZ Beacon 1	6-13
6.3.7	Manual Beacon Frequencies	6-14
6.3.8	Easy Satellite DGPS Configuration (AgGPS 132 Only)	6-15
6.3.9	Satellite Frequency (AgGPS 132 Only)	6-16
6.3.10	Satellite Baud	6-17
6.3.11	OmniSTAR Activation	6-17
6.3.12	Racal Solution	6-18
6.4	Configuring Port Parameters	6-19
6.4.1	Setting the Port Input Parameters	6-20
6.4.2	Setting the Port Output Parameter	6-21
6.4.3	NMEA 1 Settings	6-22
6.4.4	NMEA 2 Settings	6-23

6.4.5	NMEA 3 Settings	6-23
6.4.6	Message Rate	6-24
6.5	Configuring CAN Parameters	6-25
6.5.1	CAN Rate	6-26
6.5.2	Address	6-26
6.5.3	Message Tape	6-27
6.5.4	Interval.	6-28
6.6	Base Station Configuration	6-29
6.6.1	Base Location	6-30
6.6.2	Enabling Base Mode.	6-34
6.6.3	Port A Output	6-35
6.6.4	Port B Output	6-35

7 Troubleshooting

7.1	Increasing GPS Accuracy	7-1
7.2	Intermittent GPS Loss	7-3
7.3	Power Lines and Strong Magnetic Fields	7-3
7.4	Choosing an Antenna Location.	7-4
7.5	Checking for Antenna Cable Failure	7-4
7.6	Why Beacon DGPS Works In Some Places But Not Others.	7-4
7.7	Reducing Engine Noise.	7-5
7.8	Determining if the Beacon is Operable.	7-5
7.9	Losing the Beacon Signal at Night	7-5
7.10	Using the Optional TSIP Talker Software	7-6
7.11	Why Satellite DGPS Works in Some Places But Not Others	7-6
7.12	Interfacing the Receiver With Other RTCM Sources	7-6
7.13	Verifying the RTCM Source is Outputting Messages	7-7
7.14	Verifying the Unit is Outputting NMEA Messages	7-7
7.15	Losing Configuration Settings When the Receiver is Powered Off	7-7
7.16	The Receiver Front Bulges Out.	7-8

7.17	Restoring the Receiver to Factory Defaults	7-8
7.18	Troubleshooting Guides	7-9

A Specifications

B Receiver Defaults

C Cables and Connectors

C.1	Port A and Port B Connectors	C-2
C.2	Standard Data/Power Cable	C-3
C.3	Ag Leader Interface Cable	C-4
C.4	Dual Data Interface Cable	C-5
C.5	Case AFS Cable	C-6
C.6	John Deere GreenStar Data Cable	C-6
C.7	RDS Data Power Cable.	C-7
C.8	Windows CE Cable.	C-8

D NMEA-0183 Sentences

D.1	NMEA-0183 Sentence Structure	D-1
D.1.1	Symbols and Delimiters	D-3
D.1.2	Checksum Values	D-4
D.1.3	Field Formats	D-4
D.1.4	Null Fields	D-4
D.1.5	Talker ID Codes	D-5
D.1.6	Latitude and Longitude Values	D-5
D.1.7	Time Values	D-5
D.1.8	Other Values	D-6
D.1.9	Reading NMEA String Format	D-6
D.2	NMEA Sentence Summary.	D-6
D.3	ALM Sentence	D-8

D.4	GBS SentenceD-9
D.5	GGA SentenceD-10
D.6	GLL SentenceD-11
D.7	GRS SentenceD-12
D.8	GSA SentenceD-13
D.9	GST Sentence.D-14
D.10	GSV SentenceD-15
D.11	MSS SentenceD-16
D.12	RMC SentenceD-17
D.13	VTG SentenceD-19
D.14	XTE SentenceD-20
D.15	ZDA SentenceD-21
D.16	PTNLAG001 Proprietary Sentence.D-22
D.17	PTNLID Proprietary SentenceD-23
D.18	PTNLDG Proprietary SentenceD-24
D.19	PTNL,GGK Sentence.D-26
D.20	PTNLISM Proprietary SentenceD-27

E Flash Loader 100

E.1	Connecting to the Flash Loader SoftwareE-2
E.2	Using Flash Loader 100E-3
E.3	Running Flash Loader 100E-4

F Activating a Satellite DGPS Service

F.1	OmniSTAR ActivationF-3
F.2	Racal ActivationF-5

List of Figures

Figure 1-1	AgGPS Receiver	1-1
Figure 1-2	Back Panel	1-13
Figure 2-1	Antenna Cable Connections	2-8
Figure 2-2	External Device Cable Connections	2-10
Figure 2-3	CASE AFS Power/Data Cable Connection	2-12
Figure 2-4	GreenStar Data Cable Connection	2-13
Figure 2-5	Ag Leader Power/Data Cable Connections	2-15
Figure 2-6	Power/Data RTCM/NMEA Cable Connections.	2-16
Figure 3-1	AgGPS Screen Hierarchy	3-2
Figure 3-2	AgGPS 124 and 132 Receiver Front Panel.	3-3
Figure 3-3	Home Screen Hierarchy	3-5
Figure 3-4	GPS Status	3-7
Figure 3-5	Beacon DGPS Status	3-8
Figure 3-6	Satellite DGPS Status.	3-9
Figure 4-1	Operation Screen Hierarchy	4-1
Figure 4-2	Area Calculation Screen.	4-3
Figure 5-1	Status Screen Hierarchy	5-2
Figure 5-2	Location	5-4
Figure 5-3	Altitude	5-5
Figure 5-4	Velocity	5-6
Figure 5-5	GPS Satellite Information	5-7
Figure 5-6	DOPs	5-9
Figure 5-7	Beacon Status.	5-11

List of Figures

Figure 5-8	Alternate Beacon	5-12
Figure 5-9	DGPS Data Source	5-13
Figure 5-10	DGPS Age	5-14
Figure 5-11	Satellite Differential Status.	5-16
Figure 5-12	Service Provider ID	5-17
Figure 5-13	DGPS Data Source	5-18
Figure 5-14	DGPS Age	5-19
Figure 5-15	Time	5-23
Figure 5-16	Date and GPS Week	5-24
Figure 5-17	Receiver Serial Number	5-25
Figure 5-18	Firmware Version and Date	5-26
Figure 5-19	System Voltages	5-28
Figure 5-20	Channel A Status	5-30
Figure 6-1	Configuration Screen Hierarchy.	6-2
Figure 7-1	System Hardware and Power Check Guide	7-9
Figure 7-2	GPS Reception Troubleshooting Guide	7-11
Figure 7-3	GPS Reception Troubleshooting Guide - Using a Yield Monitor	7-13
Figure 7-4	Beacon Troubleshooting Guide	7-15
Figure 7-5	OmniSTAR Troubleshooting Guide	7-17
Figure 7-6	Racal-LandStar Troubleshooting Guide.	7-19
Figure D-1	Sample ZDA Sentence Structure	D-1
Figure F-1	OmniSTAR Activation Guide.	F-3
Figure F-2	Racal-LandStar Activation Guide	F-5

List of Tables

Table 2-1	AgGPS 132 Only Components	2-2
Table 2-2	AgGPS 124 Only Components	2-2
Table 2-3	AgGPS Receiver Components	2-2
Table 2-4	AgGPS Receiver Enhancements.	2-3
Table 2-5	AgGPS Application Options	2-3
Table 2-6	Optional Components.	2-4
Table 3-1	Keypad Actions	3-4
Table 3-2	Position Types	3-7
Table 3-3	Options in Beacon Operating Mode	3-9
Table 3-4	DGPS Signal-to-Noise Values	3-10
Table 3-5	Satellite Differential Mode Status Indicators.	3-10
Table 4-1	Area Calculation Functions	4-4
Table 5-1	Types of Recorded Positions	5-4
Table 5-2	Position Dimensions	5-4
Table 5-3	Heading Values	5-6
Table 5-4	Incomplete Satellite Data Messages	5-8
Table 5-5	Racal-LandStar Subscription Options	5-20
Table 5-6	OmniSTAR Subscription Options	5-21
Table 5-7	Receiver Options	5-27
Table 5-8	Channel Status	5-30
Table 6-1	GPS Mode Settings.	6-4
Table 6-2	PDOP Mask and 2D-3D Settings	6-6
Table 6-3	PV Filter and Position Rate Settings	6-7

List of Tables

Table 6-4	DGPS Mode Settings	6-9
Table 6-5	DGPS Source Settings	6-10
Table 6-6	Beacon Mode Settings	6-11
Table 6-7	Racal Station Settings.	6-18
Table 6-8	Port Input Parameter Settings.	6-20
Table 6-9	Port Output Parameter Settings	6-21
Table 6-10	Messages.	6-27
Table A-1	AgGPS 124 and 132 Receiver	A-1
Table A-2	Combined Antenna.	A-2
Table A-3	GPS Channels.	A-3
Table A-4	Beacon Channels	A-3
Table A-5	L-Band Satellite Differential Correction Receiver with Multiple Vendor Support (AgGPS 132 only).	A-4
Table B-1	Receiver Defaults	B-1
Table C-1	Connector Pin-out for AgGPS 124 and 132 Port A and Port B .	C-2
Table C-2	Standard Data/Power Cable Pin-out (P/N 30945)	C-3
Table C-3	Ag Leader Yield Monitor Cable Pin-out (P/N 30660)	C-4
Table C-4	Dual Data Interface Cable Pin-out (P/N 32015).	C-5
Table C-5	Case AFS Cable Pin-out (P/N 32609)	C-6
Table C-6	John Deere GreenStar Data Cable Pin-out (P/N 34189)	C-6
Table C-7	RDS Data Power Cable Pin-out (P/N 35142).	C-7
Table C-8	Windows CE Cable Pin-out (P/N 35283)	C-8
Table D-1	Sample ZDA Sentence Structure	D-2
Table D-2	Supported Talker ID Codes	D-5
Table D-3	Supported NMEA-0183 Sentences.	D-7
Table D-4	ALM Sentence Fields.	D-8
Table D-5	GBS Sentence Fields	D-9
Table D-6	GGA Sentence Fields	D-10
Table D-7	GLL Sentence Fields	D-11
Table D-8	GRS Sentence Fields	D-12

Table D-9	GSA Sentence Fields	D-13
Table D-10	GST Sentence Fields	D-14
Table D-11	GSV Sentence Fields	D-15
Table D-12	MSS Sentence Fields	D-16
Table D-13	RMC Sentence Fields	D-17
Table D-14	VTG Sentence Fields	D-19
Table D-15	XTE Sentence Fields	D-20
Table D-16	ZDA Sentence Fields	D-21
Table D-17	PTNLAG001 Sentence Fields	D-22
Table D-18	PTNLID Sentence Fields	D-23
Table D-19	PTNLDG Sentence Fields	D-25
Table D-20	PTNL,GGK Sentence Fields	D-26
Table D-21	PTNL,SM Sentence Fields	D-27
Table E-1	Flash Loader 100 Options	E-3

About This Manual

Welcome to the *AgGPS 124 /132 Operation Manual*. This manual describes how to install and configure the AgGPS™ 124 and 132 receivers. It includes step-by-step instructions for installing the AgGPS receiver and guidelines for using the LCD screen display to view and configure operating parameters. Also included are guidelines for interfacing the receiver to a PC and agricultural instruments, information about the selection of NMEA messages supported by the receiver, and connector pin-out diagrams for Port A, Port B, and cable connections.

Scope and Audience

Even if you have used other Global Positioning System (GPS) products before, we recommend that you spend some time reading this manual to learn about the special features of this product. If you are not familiar with GPS, we suggest that you read the booklet *GPS, A Guide to the Next Utility*, available from Trimble.

The following sections provide a guide to this manual, as well as to other documentation that you may have received with this product.

Organization

This manual contains the following:

- Chapter 1, Overview, provides a brief overview of Differential GPS, and AgGPS 124 /132 components.
- Chapter 2, Installing the AgGPS Receiver, contains installation and interfacing instructions for the AgGPS 124 and 132 receivers.
- Chapter 3, Getting Started, gives instructions for using the AgGPS 124 /132 display and keypad.
- Chapter 4, Operation Screens, shows you how to record line length and field area.
- Chapter 5, Status, explains the status screens.
- Chapter 6, Configuring the AgGPS 124 and 132 Receiver, gives instructions for configuring AgGPS 124 /132 operating parameters.
- Chapter 7, Troubleshooting, gives guidelines for solving potential problems.
- Appendix A, Specifications, identifies the physical characteristics and general specifications of the AgGPS 124 and 132 receivers.
- Appendix B, Receiver Defaults, contains the default settings for the AgGPS 124 and 132 receivers.
- Appendix C, Cables and Connectors, includes pin-out diagrams for the standard and optional cables.
- Appendix D, NMEA-0183 Sentences, describes the structure of NMEA messages generated by the AgGPS 124 and 132 receivers and the information included in them.
- Appendix E, Flash Loader 100, explains how to use the Flash Loader 100 software to update the receiver firmware.

- Appendix F, Activating a Satellite DGPS Service, provides step-by-step instructions for activating a satellite DGPS service. (AgGPS 132 only)

Related Information

The following sections discuss other sources of information that introduce, extend, or update this manual.

Update Notes

There is a warranty activation sheet with this product. Send it in to receive update notes automatically as they become available. These contain important information about software and hardware changes. Contact your local Trimble Dealer for more information about the support agreement contracts for software and firmware.

Other Information

This section lists sources that provide other useful information.

World Wide Web (WWW) Site

For an interactive look at Trimble, visit our site on the World Wide Web:

- www.trimble.com

File Transfer Protocol (FTP) Site

Use the Trimble FTP site to send files or to receive files such as software patches, utilities, and FAQs. The address is:

- <ftp://ftp.trimble.com>

You can also access the FTP site from the Trimble World Wide Web site (www.trimble.com/support/support.htm).

Technical Assistance

If you have a problem and cannot find the information you need in the product documentation, ***contact your local dealer.***

If you need further assistance, contact the Trimble Technical Assistance Center (TAC) by phone, fax, or email. A support technician can help determine the cause of the problem and provide technical assistance.

To contact TAC:

Phone: +1-800-SOS-4TAC (North America)
+1-408-481-6940 (International)

Phones are answered from 6 am to 5.30 pm Pacific Standard Time.

Fax: +1-408-481-6020

Email: trimble_support@trimble.com

When you contact TAC, have the following information available:

1. The Trimble product name, any software or firmware version number(s), and if appropriate, the serial number.
2. Your specific question or problem.

Please detail background information, such as the configuration of your data collector or receiver, and the exact type, make, and configuration of your computer. If you have received error messages, please specify the exact wording.

If you need to send a data file along with your inquiry, please compress the file using PKZIP Software by PKWARE, Inc., and name the file with the extension .ZIP.

Use one of the following methods to send the file:

- Attach the file to your email inquiry.
- Put the file on the Trimble FTP site and include the filename in your email inquiry.

Reader Comment Form

Thank you for purchasing this product. We would appreciate feedback about the documentation. Use the reader comment form at the back of this manual or, if this is not available, send comments and suggestions to the address in the front. All comments and suggestions become the property of Trimble Navigation Limited.

Document Conventions

Italics identify software menus, menu commands, dialog boxes, and the dialog box fields.

SMALL CAPITALS identify DOS commands, directories, filenames, and filename extensions.





Courier represents messages printed on the screen.

Courier Bold represents information that you must type in a software screen or window.

Helvetica Bold identifies a software command button.

Return or Ctrl + C identifies a hardware function key or key combination that you must press on a PC.

Screen Font is used to show information displayed on the AgGPS 124 /132 LCD display.

, , , and  are the buttons on the AgGPS 124 /132 front panel.

Warnings, Cautions, Notes, and Tips

Warnings, cautions, notes, and tips draw attention to important information and indicate its nature and purpose.



Warning – Warnings alert you to situations that could cause personal injury or unrecoverable data loss.



Caution – Cautions alert you to situations that could cause hardware damage or software error.



Note – Notes give additional significant information about the subject to increase your knowledge, or guide your actions.



Tip – Tips indicate a shortcut or other time- or labor-saving hint that can help you make better use of the product.

1 Overview

The AgGPS receivers combine high-performance GPS reception with radiobeacon DGPS capability in a single, lightweight, durable, waterproof housing.

Additionally, the AgGPS 132 receiver (see Figure 1-1) contains The Choice™ technology, enabling OmniSTAR and Racal LandStar real-time differential capabilities.



Figure 1-1 AgGPS Receiver

As a part of a precision agriculture system, the AgGPS receiver outputs submeter GPS position information to a variety of farming equipment, including yield monitors, parallel swathing guidance systems, variable rate planters, spray application and soil sampling controllers, and portable field computers.

The AgGPS receivers output real-time submeter positions and 0.1 mile-per-hour (0.16 kph) velocity accuracy through NMEA-0183 and TSIP (Trimble Standard Interface Protocol) messages. A 1 PPS (pulse per second) strobe signal can also be used to synchronize time and log event marker input when using external instruments.

1.1 Differential GPS Positioning

The AgGPS receivers use differential GPS (DGPS) to achieve submeter (<3.28 ft) accuracy. DGPS requires two or more receivers. One receiver, called the reference or base station, is located at a known point to determine the GPS measurement errors. An unlimited number of mobile AgGPS receivers, sometimes called rovers, collect data at unknown locations within the transmission range of the reference station. The reference station broadcasts correction values, which are applied to the AgGPS receiver position. Errors common at both the reference and rover receivers are corrected.

1.1.1 Sources of GPS Error

The largest source of GPS position error is Selective Availability (S/A). S/A is induced by the U.S. government for the purpose of restricting full GPS accuracy to all except authorized users. The magnitude of S/A combined with other error sources results in autonomous (single receiver) horizontal accuracies of up to 100 meters (328 feet). If the U.S. government turns S/A off, autonomous GPS horizontal accuracy would be about 10 meters (32.8 feet).

Atmospheric conditions (especially in the ionosphere), multipath (GPS signals bouncing off objects before reaching the antenna), and receiver (electronic) noise are in large part responsible for the remaining 10 meters (32.8 feet) of error.

DGPS removes most of the errors caused by S/A and the atmosphere. The AgGPS receivers use the latest advancements in receiver design to minimize these errors. For more information about S/A, atmospheric effects, and other sources of error, review *All About GPS* tutorials found on the Trimble web site (WWW.TRIMBLE.COM).

1.1.2 DGPS Accuracy

Accuracy of the AgGPS receiver with differential correction is better than 1 meter RMS (3.2 feet) + 10 ppm times the distance between the reference station and the mobile receiver given the following conditions:

- Number of satellites used: > 5
- PDOP: < 4
- Signal to Noise Ratio: > 6
- Satellite Elevation Mask: > 7.5
- Low multipath environment
- RTCM-compatible corrections broadcast from a Trimble 4000RSi or equivalent

Number of visible satellites

Four or more satellites must be visible to calculate a three-dimensional position (latitude and longitude, altitude, and time). Three or more satellites must be visible to calculate a two-dimensional position (latitude and longitude, and time). One or more satellites must be visible to compute a zero-dimensional (time only) position. Three-dimensional positions are most accurate. On the AgGPS receiver you can set configurations to determine how many satellites are used to compute GPS positions.

Position Dilution of Precision (PDOP)

PDOP is a unitless measure indicating when the satellite geometry can provide the most accurate results. When satellites are spread around the sky, the PDOP value is low and the computed position is most accurate. When the satellites are grouped closely together, the PDOP is high and positions are less accurate. You can configure a PDOP Mask to control the point at which the AgGPS receiver stops outputting position reports. For submeter accuracy, the PDOP must be 4 or less.

In some agricultural applications, a PDOP Mask of 12 or more can be used to prevent loss of data. However, accuracy can suffer as PDOP rises. There is a trade-off between optimal GPS accuracy and continuous operation.

Signal-to-Noise Ratio

Signal-to-Noise Ratio (SNR) is a measure of the satellite signal strength. Accuracy improves as the signal strength increases. More signal with less noise equals better accuracy. To compute positions with strong signals, the SNR mask should be set to the default, 6 or more.

Elevation Mask

When a satellite is low on the horizon, the GPS signals must travel a great distance through the atmosphere, delaying reception by the AgGPS receiver. You can minimize noisy data by adjusting (tuning) the Elevation Mask. Satellites below the mask are excluded from the position computation. The recommended setting for highest accuracy is 8°. There is a trade-off between accuracy and continuous operation; lowering the mask ensures continuous operation.

Multipath

GPS signals are sometimes reflected off nearby objects, particularly metallic objects, creating false or erroneous results. This phenomenon is known as multipath. Severe multipath can induce errors of many meters, while mild multipath may cause small, undetectable errors. Optimal accuracy is obtained by collecting data in an environment that is devoid of large reflective surfaces, like buildings and trees. The AgGPS receiver Everest™ multipath reduction option helps reduce the effects of multipath.

Base station receiver

AgGPS receiver differential position accuracy is dependent upon the differential correction quality supplied in the RTCM SC-104 message format.

1.2 Measuring GPS Accuracy

To measure GPS accuracy you must have some knowledge of coordinates and datums. When comparing geographic data obtained from different sources, the data must be referenced to the same datum and coordinate system. Different datums and coordinate systems provide different coordinate values for any geographic location.

In North America, for example, two different datums, NAD 27 and NAD 83, are commonly used. A particular place on the surface of the earth has different latitude and longitude coordinates in each datum. The AgGPS receivers provide coordinates in the NAD 83 datum. Existing background maps for the NAD 27 datum do not register with GPS data based on the NAD 83 datum.



Note – The North American Datum 1983 (NAD 83) is, for all practical purposes, equivalent to WGS-84 (World Geodetic Survey 1984). GPS data is referenced to the WGS-84 datum.

1.2.1 Receiving Beacon DGPS

To utilize free radiobeacon differential signals, the AgGPS receivers use dual-channel, fully-automatic beacon receiver electronics for tracking broadcasts conforming to the IALA Standard. The default configuration when using beacon DGPS allows the AgGPS receiver to determine the ten most powerful radiobeacons in your vicinity. The closest beacon is used. Both Beacon channels are configured to search and track the two nearest radiobeacons in the database.

The receiver can also be configured to search for user-defined station frequencies. The EZ beacon feature enables easy local beacon selection.

The AgGPS receivers continuously monitor the integrity of the data received from the differential radiobeacon(s). If excessive errors in the data stream are found, the receiver automatically switches to a different radiobeacon, if one is available.

Radiobeacon signals propagate through ground and sky waves. Hilly and mountainous terrains generally do not affect the beacon reception. Near the beacon transmitter the signal can be received even in canyons. Canopy has no effect on signal reception.

Beacon signals are greatly effected by natural and human-made noise. Lightning, automobile ignition, electric motor, and high voltage power lines can be a severe source of noise. In addition, during night hours at longer distances from the beacon station (240 to 480 Km or 150 to 300 mi), the sky wave (reflected off the ionosphere) can interfere with the ground wave beacon signal. This self-jamming at night may be a problem with stronger beacon stations. Integrity monitoring of the beacon frequency can be performed with the optional TSIP Talker software.



Note – A phenomenon called geographic de-correlation, causes radiobeacon signals to become less accurate as the distance from the base station increases. The amount of beacon accuracy degradation depends on the ionosphere and the amount of Selective Availability. Degradation can be as much as 1 meter (3 feet) for every 100 km (60 miles).

1.2.2 Receiving Satellite DGPS (AgGPS 132 only)

Satellite differential GPS signals are sent from a ground station through a satellite transponder to users within view of the satellite. The corrections are sent in a format that allows the construction of a local differential correction applicable to the entire coverage region.

The AgGPS receiver contains both OmniSTAR and Racal-LandStar satellite differential technology. To enable satellite differential capabilities, contact either supplier. Depending on which supplier is involved, the receiver can be activated by an on-the-air signal or an encrypted activation message entered on the receiver front panel.

Satellite differential signals provide valid corrections over a large area, but are decoded to provide an accurate correction applicable to any location within the satellite view area. This is accomplished by special software algorithms for generating wide area differential corrections. These algorithms, called Virtual Reference Station (VRS) and Virtual Base Station (VBS), depending on the vendor, compute differential corrections that a base station would generate if it were at the receiver's location. This correction is constantly updated, so as the receiver moves around, the correction remains at full accuracy.

Satellite differential signals are line-of-sight and can be blocked by a mountain, hill, or tree canopy. Wet canopy, from a heavy rain, reduces the signals even more. The same local environmental factors, like radar and microwave transmitters, that affect the GPS signals can interfere with the satellite signals. Power lines usually have no effect.

For specific information about the providers, visit WWW.OMNISTAR.COM or WWW.RACAL-LANDSTAR.COM on the World Wide Web.

1.3 Standard Features

The standard AgGPS 124 and 132 system provides the following:

- 12 GPS (C/A-code) tracking channels, carrier-phase filtering
- Submeter differential accuracy (RMS): assumes at least 5 satellites and PDOP less than 4
- Combined GPS/DGPS antenna
- Magnetic antenna mount
- 5-meter ruggedized antenna cable
- Data/Power cable
- LCD display with four-button keypad to configure and view system properties
- Two RS-232 serial and CAN-ready ports:
 - NMEA-0183 output: ALM, GGA, GLL, GSA, GSV, MMS, RMC, VTG, ZDA (The default NMEA messages are GGA, GSA, and VTG)
 - RTCM SC-104 input and output
 - TSIP input and output
 - Outputs 1 PPS (pulse per second) strobe signal on either serial port, allowing an external instrument to synchronize its internal time with the AgGPS clock oscillator.

1.4 Receiver Enhancements

AgGPS systems contain several purchase options designed to maximize receiver performance. Depending on the system you ordered, the following options may or may not be included.

1.4.1 Fast Rate (P/N 33176-10)

The Fast Rate option enables the AgGPS receiver to output position data up to 10 times per second. Fast Rate output is important in parallel swathing and variable rate applications. (A 5 Hz Fast Rate option is included with the Parallel Swathing Option.)

1.4.2 Differential Base Station (P/N 33176-30)

The Differential Base Station option enables the AgGPS receiver to output RTCM differential corrections. With a radio link, these corrections can be broadcast and used by other DGPS receivers.

1.4.3 Everest Technology (P/N 33176-40)

The Everest™ multipath reduction option improves DGPS receiver accuracy by filtering reflected GPS signals before they are processed by the DGPS receiver. Everest technology provides maximum accuracy near trees, buildings, and reflective surfaces. (The Everest multipath reduction option is included with the Parallel Swathing Option.)

1.5 Application Options

The AgGPS system contains several purchase options that increase the number of applications for which the AgGPS receivers can be used.

1.5.1 Parallel Swathing (P/N 34623)

The AgGPS Parallel Swathing option enhances the AgGPS receiver with an easy-to-use, plug-and-play lightbar. The lightbar indicates off-track error, which the operator uses to steer back on-line.

The AgGPS Parallel Swathing Option helps reduce farm expenses by minimizing redundant applications and skipped areas. Efficient field coverage enables maximum ground coverage in the shortest possible time.

Independent data ports enable the AgGPS receiver to simultaneously operate the lightbar and output data to a variable rate controller or other device.

1.5.2 Ag Field Pack (P/N 32294)

The Ag Field Pack includes the lumbar pack, antenna poles, batteries, and cables to keep hands free when operating the AgGPS receiver on foot. The Field Pack is ideal for crop scouting and field mapping applications.

1.6 Receiver Connections

Figure 1-2 shows the AgGPS receiver back panel and its associated ports.




Figure 1-2 Back Panel

Both Port A and Port B can accept power. The standard power/data cable (P/N 30945) supplies power.

1.6.1 ASCII, TSIP, and RTCM Input

Both Port A and Port B are used to input ASCII, TSIP, RTCM, and CAN data from an external device. ASCII data can be received from an external sensor, converted into a NMEA message, and exported to another device. TSIP command packets are used to set and monitor GPS and Beacon parameters from the optional TSIP Talker software. RTCM data can be input from an external source such as an FM pager.

1.6.2 RTCM, TSIP and NMEA Output

Both Port A and Port B are used to output RTCM, TSIP, NMEA 0183 or CAN messages to an interface device. RTCM is output when operating in base mode. TSIP is output when communicating with the optional TSIP Talker software. NMEA is output when exporting GPS position information to an external device, such as a yield monitor. CAN is used when operating a CAN bus.

1.6.3 1 PPS Output

Either port can output a 1 PPS (pulse per second) strobe signal to synchronize the external instruments to the receiver's internal clock.

2 Installing the AgGPS Receiver

This chapter shows you how to:

- unpack and inspect the shipment
- install the following:
 - AgGPS receiver
 - antenna
 - interface devices

We recommend you read this chapter before attempting to install your AgGPS receiver.

2.1 Unpacking and Inspecting the Shipment

Inspect the shipping cartons for any signs of damage or mishandling before unpacking the receiver.

Report any damage to the shipping carrier immediately.

2.1.1 Opening the Shipping Carton

The shipment could include one or more cartons, depending on the number of optional accessories ordered. Open the shipping cartons and make sure that all of the components indicated in Tables 2-1 through 2-3 are included.

Table 2-1 AgGPS 132 Only Components

Qty	P/N	Description
1	33302-01	AgGPS 132 Receiver
1	33580-00	AgGPS Antenna

Table 2-2 AgGPS 124 Only Components

Qty	P/N	Description
1	33606-00	AgGPS 124 Receiver
1	29635-50	AgGPS 124 Antenna

Table 2-3 AgGPS Receiver Components

Qty	P/N	Description
1	12920-00	Magnetic Mount for Antenna
1	32608	5-meter (16-foot) Ruggedized Antenna Cable
1	30945	Data/Power Cable
1	33301-00	AgGPS 124/132 Operation Manual
1	11093	Coax Tape Seal
1	25110-00	Warranty Activation Card

As shown in Table 2-4, the bill of lading could list one or more of the following factory installed enhancements.

Table 2-4 AgGPS Receiver Enhancements

Qty	P/N	Description
1	33176-10	Fast rate capability
1	33176-30	DGPS Base capability
1	33176-40	Everest multipath reduction technology

As shown in Table 2-5, the bill of lading could list one or more of the following options.

Table 2-5 AgGPS Application Options

Qty	P/N	Description
1	32294-00	Ag Field Pack 120 volts
1	32294-10	Ag Field Pack 240 volts
1	34623-00	Parallel Swathing

The bill of lading could include one or more of the items listed in Table 2-6 if optional components or accessories are ordered.

Table 2-6 Optional Components

Qty	P/N	Description
1	29510	10-meter (32-foot) Antenna Cable
1	30660	Ag Leader Power/Data Cable
1	30700	3.6-meter (12-foot) Extension Data Cable DE9-M to DE9-F
1	32015	Power/Data Cable RTCM/NMEA
1	32609	CASE AFS Power/Data Cable
1	34189	John Deere GreenStar Data Cable
1	35142	RDS Cable
1	38112	Receiver ceiling mounting bracket
1	30661	Windows CE Cable with Power Leads
1	35283	Windows CE Cable with Cigarette Power Adapter

2.1.2 Reporting Shipping Problems

Report any problems discovered after you unpack the shipping cartons to both Trimble Customer Support and the shipping carrier.

2.2 Installation Guidelines

AgGPS receivers are designed to be mounted on a flat surface in any orientation. The bottom of the receiver has mounting flanges for securing to a flat surface with screws. For ceiling mounts, ask your local dealer about Trimble's ceiling mounting bracket.

2.2.1 Choosing a Location

The AgGPS receiver can be installed in any convenient location close to the external device. The location you choose should:

- allow visibility of the front panel
- provide clearance for the antenna and interface connections
- be within 3.6 meters (12 feet) of the external instrument port (The optional 3.6-meter (12-foot) extension cable can be used.)

2.2.2 Considering Environmental Conditions

Although the AgGPS receiver is located within a waterproof housing, it should be installed in a dry location. Avoid exposure to extreme environmental conditions, including:

- water
- excessive heat ($> 65^{\circ}\text{C}$ or 149°F)
- excessive cold ($< -20^{\circ}\text{C}$ or -4°F)
- high vibration
- corrosive fluids and gases

Avoiding these conditions improves the receiver's performance and long-term product reliability.

2.3 Mounting the Receiver

To mount the receiver:

1. Drill four holes in the mounting surface using the slotted holes in the mounting brackets as a template.



Note – If machine screws are used, tap the mounting holes to fasten the receiver to the mounting surface. Use 8-32 socket head cap screws to fasten the receiver to the mounting surface. Alternatively, use self-tapping screws to secure the receiver.

2. Use screws to secure the brackets to the mounting surface.

2.4 Mounting the Antenna

Choose a location for the antenna that is safe from damage during normal operation. The antenna can be mounted to a flat surface using the magnetic mount. Use the following guidelines when selecting a location:

- Place the antenna on a flat surface along the center line of the vehicle.
- Choose an area with clear view to the sky above metallic objects. The top of a mast or pole is recommended.
- Do not mount the antenna close to stays, electrical cables, metal masts, and other antennas.
- Do not mount the antenna near transmitting antennas, radar arrays, or satellite communication equipment.
- Avoid areas with high vibration, excessive heat, electrical interference, and strong magnetic fields.



Caution – A grain tank extension may block low elevation satellites.

2.4.1 Sources of Electrical Interference

Several sources of electrical and magnetic noise are:

- gasoline engines (spark plugs)
- televisions and PC monitors
- alternators and generators
- electric motors
- propeller shafts
- equipment with DC-to-AC converters
- florescent lights
- switching power supplies



Note – You can check the antenna installation for locally generated noise by connecting a PC to the receiver and running the optional TSIP Talker program. If you observe interference, move the antenna to a different location. Raising the antenna several decimeters may minimize the noise. TSIP Talker can be downloaded from Trimble's FTP site: <ftp.trimble.com>.

2.5 Routing and Connecting the Antenna Cable

A 5-meter (16.5-foot) antenna cable is included with your AgGPS receiver (see Figure 2-1). One end of the antenna cable features a 90-degree connector. The opposite end features a straight connector. Connect the 90-degree connector to the antenna, then route the cable to the receiver.




Figure 2-1 Antenna Cable Connections

When routing the antenna cable, avoid the following hazards:

- sharp ends or kinks in the cable
- hot surfaces (exhaust manifolds or stacks)
- rotating or reciprocating equipment
- sharp or abrasive surfaces
- door and window jams
- corrosive fluids or gases

After routing the cable, connect it to the AgGPS receiver. Use tie-wraps to secure the cable at several points along the route. One tie-wrap is required to secure the cable near the base of the antenna. This provides strain relief for the antenna cable connection.

When the cable is secured, coil any slack. Secure the coil with a tie-wrap and tuck it in a safe place.



Tip – Use the coax seal tape, provided with the antenna, to seal the antenna connector at the antenna. The tape prevents water and moisture from entering the connection.

2.6 Connecting External Devices

After installing the antenna and receiver, connect and route the interface cables. The receivers can be powered by a vehicle or a customer supplied 12-volt switched power source. Once the receiver is installed and powered on, the front panel LCD screen lights.

The following sections contain installation instructions for different power/data cables. Depending on the cable(s) you own, complete the appropriate installation.

2.6.1 Connecting the Standard Data/Power Cable (P/N 30945)

The Standard Data/Power Cable connects the AgGPS receiver to many types of external devices (see Figure 2-2).




Figure 2-2 External Device Cable Connections

To connect the AgGPS receiver to an external device:

1. Connect the CONXALL right angle connector to either port on the AgGPS receiver.
2. Connect the 9-pin DE-9 Male connector to the external device DE-9 Female connector.
3. Connect the power leads to a switched power source.



Note – The red lead must be connected to the +12 volts and the black lead to Ground.

4. Coil excess slack and secure the cable.



Tip – Install the optional 3.6-meter (12-foot) Extension Cable (P/N 30700) to extend the Standard Data/Power Cable (P/N 30945) to 7.2 meters (24 feet).

2.6.2 Connecting the Optional CASE AFS Power/Data Cable (P/N 32609)

The 1-meter (3-foot) CASE AFS Power/Data Cable connects the AgGPS receiver to a CASE AFS installation.




Figure 2-3 CASE AFS Power/Data Cable Connection

To connect the AgGPS receiver to a CASE AFS installation:

1. Connect the straight CONXALL connector to Port A on the AgGPS receiver.
2. Connect the 5-pin connector to the CASE AFS wiring harness.
3. Coil excess slack and secure the cable.

2.6.3 Connecting the Optional John Deere GreenStar Data Cable (P/N 34189)

The 1-meter (3-foot) John Deere GreenStar Data Cable connects the AgGPS receivers to the John Deere GreenStar system (see Figure 2-4).




Figure 2-4 GreenStar Data Cable Connection

Before installing the AgGPS receiver, you *must* determine if there is a GPS receiver currently attached to the GreenStar System.

- If there is *not* a GPS receiver attached to the GreenStar system, proceed with Step 1.
- If there is a GPS receiver attached to the GreenStar system, disconnect it from the wiring harness. This is required to activate the GreenStar RS 232 port. The harness can be disconnected from the receiver at the antenna located above the grain tank. When disconnected, proceed with Step 1.

To connect the AgGPS-series receiver to the John Deere GreenStar system:

1. Inside the cab behind the seat, locate the wiring harness that connects to the GreenStar mapping processor. From this wiring harness, gently pull the three short wires from the casing. (They are approximately 10 inches long; orange, black and blue; and sealed with shrink wrap). You do not use the blue cable.
2. Connect the orange wire labeled 967 to the Metripack connector pin. Insert the pin into the Metripack connector (P/N 12015793) slot A.
3. Connect the black wire labeled 20E to the Metripack connector pin. Insert the pin into the Metripack connector (P/N 12015793) slot C.
4. Connect the AgGPS-GreenStar cable (P/N 34189) to the Metripack connector (P/N 12015793).
5. Connect the data/power cable (P/N 30945) to the AgGPS-GreenStar cable (P/N 34189).
6. Attach the data power cable (P/N 30945) to port A of the AgGPS receiver.
7. Attach the power leads of the data/power cable (P/N 30945) to switched power. Connect the red wire to positive and the black wire to negative.

2.6.4 Connecting the Optional Ag Leader Power/Data Cable (P/N 30660)

The 3.6-meter (12-foot) Ag Leader Yield Monitor Cable connects AgGPS receivers to an Ag Leader Yield Monitor (see Figure 2-5).




Figure 2-5 Ag Leader Power/Data Cable Connections

To connect the AgGPS receiver to an Ag Leader Yield Monitor:

1. Connect the CONXALL right-angle connector to either port on the AgGPS receiver.
2. Connect the 9-pin DE-9 Male connector to the data/power port on the Ag Leader Yield Monitor.
3. Coil excess slack and secure the cable.



Tip – Install the optional 3.6-meter (12-foot) Extension Cable (P/N 30700) to extend the Ag Leader Yield Monitor Cable to 7.2 meters (24 feet).

2.6.5 Connecting the Optional Power/Data RTCM/NMEA Cable (P/N 32015)

This cable is useful for sharing an AgGPS receiver port with several devices. One interface device can be connected to each side of the connector. This cable can also input external RTCM data while outputting NMEA to an external device (see Figure 2-6).




Figure 2-6 Power/Data RTCM/NMEA Cable Connections

To connect the optional Power/Data RTCM/NMEA cable:

1. Connect the CONXALL right-angle connector to port A on the AgGPS receiver.
2. Connect the 9-pin DE-9 Male connector(s) to the external device DE-9 Female connector.
3. Connect the power leads to a switched power source.



Note – The red lead must be connected to the +12 volts and the black lead to Ground.

4. Coil excess slack and secure the cable.

2.6.6 Connecting the Optional RDS Cable (P/N 35142)

The 3.6 meter (12 foot) RDS cable connects an AgGPS receiver to an RDS Yield Monitor.

To connect the optional RDS cable:

1. Connect the 12-pin CONXALL connector to port A on the AgGPS receiver.
2. Attach the 9-pin RS 232 Connector to the RDS Yield Monitor.

2.6.7 Connecting the Optional Windows CE with Cigarette Power Adapter Cable (P/N 35283)

The optional Windows CE cable connects an AgGPS receiver to a Windows CE computer.

To connect the optional Windows CE with Cigarette Adapter cable:

1. Connect the 12-pin CONXALL connector to port A on the AgGPS receiver.
2. Attach the 9-pin RS 232 connector to the Windows CE computer.
3. Connect the cigarette adapter to the power source.

2.6.8 Connecting the Optional Windows CE Cable (P/N 30661)

To connect the optional Windows CE cable:

1. Connect the 12-pin CONXALL connector to port A on the AgGPS receiver.
2. Attach the 9-pin RS 232 connector to the Windows CE computer.
3. Connect the power leads to a switched power source.



3 Getting Started

This chapter shows you how to use the:

- keypad on the front panel
- *Home* screen

We recommend you read through this chapter to learn basic menu operations before attempting to use your AgGPS receiver.

3.1 Using the Front Panel

After powering on the receiver, the front panel displays the *Home* screen. From the *Home* screen, press  or  to access other receiver screens. Figure 3-1 displays the screen organization. Chapters 3, 4, 5 and 6 explain each screen in detail.




Figure 3-1 AgGPS Screen Hierarchy

3.1.1 Viewing Status Screens

Figure 3-2 shows the keypad and the four keys that navigate through the AgGPS menu hierarchy.













Figure 3-2 AgGPS 124 and 132 Receiver Front Panel

Table 3-1 describes the actions performed by the keys.

Table 3-1 Keypad Actions

Key	Description
	Performs several actions: <ul style="list-style-type: none">Press  to cycle through the options displayed on a screen. When options are available, the  symbol appears in the upper right-hand corner of the screen.Press  and hold to change DGPS mode. (AgGPS 132 only)
	Cycles through the available screens.
	Cycles through the available screens.
	Moves through the main menu screens.
 + 	Moves back one level in screen hierarchy. Ultimately, it returns you to the <i>Home</i> screen. <ul style="list-style-type: none">When in a view screen described in this chapter, returns you to the <i>Home</i> screen.When in a configuration screen described in Chapter 6, Configuring the AgGPS 124 and 132 Receiver, returns you to the main menu configuration screen. Press again to return to the <i>Home</i> screen.

3.2 The Home Screen

The *Home* screen is just the first option in the main menu. The top line of the *Home* screen displays important GPS status indicators. The bottom line displays important DGPS indicators.

Figure 3-3 shows the *Home* screen and following screens.






Figure 3-3 Home Screen Hierarchy

3.2.1 Beacon and Satellite Mode Home Screens




Note – Reference to Satellite DGPS applies only to the AgGPS 132.



Tip – When in Beacon mode, a B, Beacon Searching, Beacon Tracking, or Beacon FFT message appears in the lower left corner of the screen. To change modes, press  and hold for 5 seconds. To display satellite differential information, press  until an S appears in the lower-left corner of the screen.


When beacon information appears in the *Home* screen, the AgGPS receiver operates in Beacon mode. When satellite DGPS information appears in the *Home* screen, the AgGPS 132 receiver operates in Satellite Differential mode. The DGPS source configuration setting is changed.

The following is a sample *Home* screen with Beacon DGPS:



```
← G/3D SV:07 DOP03
B A-R 310.0 S/N 15
```

The following is a sample *Home* screen with Satellite DGPS (AgGPS 132 only):



```
G/3D SV:07 DOP03
S 1556.225 S/N 15
```

Figure 3-4 explains the GPS status indicators.




Figure 3-4 GPS Status

Table 3-2 Position Types

Display	Description
SRCH	Searching for satellites.
TRCK	Tracking satellites.
G/2D	Outputting 2-dimensional autonomous positions.
G/3D	Outputting 3-dimensional autonomous positions.
D/2D	Outputting 2-dimensional differential positions.
D/3D	Outputting 3-dimensional differential positions.
Ant?	No antenna connected to receiver.



Note – The / symbol spins when the receiver is operating properly. When the / symbol is still, an error occurred.

Figure 3-5 explains the beacon DGPS status indicators.




Figure 3-5 Beacon DGPS Status

Table 3-3 describes the options available in Beacon operating mode.

Table 3-3 Options in Beacon Operating Mode

Value	Description
B	Operating in beacon mode.
Beacon Searching	Searching for beacon signals.
Beacon Tracking	The receiver is tracking beacon signals and is attempting to gain lock.
Beacon Idle	The AgGPS beacon receiver is not active.
Beacon FFT	The AgGPS receiver is looking for a beacon across the signal spectrum.
Beacon Disabled	Beacon DGPS is disabled. Check configuration settings to enable beacon DGPS.
External RTCM	Differential corrections are provided by an external source through port A or B.
Battery is Low	Warning replaces DGPS information when battery voltages are low.

Figure 3-6 explains the satellite DGPS status indicators.
(AgGPS 132 only)




Figure 3-6 Satellite DGPS Status

Table 3-4 explains signal-to-noise ratio values.

Table 3-4 DGPS Signal-to-Noise Values

Value	Description
Below 4	Unusable
4–8	Fair
>8	Excellent


Table 3-5 shows the possible satellite differential mode indicators.


Table 3-5 Satellite Differential Mode Status Indicators

Indicator	Description
S #####.### S/N ##	Operating in Satellite Differential mode.
S SRCH ###.##	Searching for Satellite Differential signal.
S TRCK #####.##	Tracking satellite without acquiring signal lock.

3.3 Below Home Screen Configurables

The *Contrast*, *Units*, *Configuration Lockout* and *Language* settings are found under the *Home* screen. To display these screens:

1. Display the *Home* screen.
2. Press  to view the *Display Options* screen.






3. Press .

3.3.1 Contrast

As lighting conditions change, the LCD display could become difficult to read. To decrease the contrast, enter a low number. Higher numbers increase screen contrast.




To change the contrast:




1. Press .
2. Press  to lighten the contrast.
3. Press  to darken the contrast.

3.3.2 Units

The *Units* screen enables the receiver to display either U.S. or Metric units. This setting does not affect data output.




To change the units:






1. Press .
2. Press  to select the appropriate units.
3. Press  to save.

3.3.3 Configuration Lockout Screen

The *Configuration Lockout* screen provides protection against tampering. To make the configuration screens invisible, input the last five digits of the receiver serial number. To view the configuration screens again, input the five-digit number a second time.




To enter the password:

1. Press  to enter the Lock Display screen.
2. Press  or  to input the values.
3. Press  to input the next number.
4. Continue until complete.
5. Press  to accept.

When complete, *Valid Password* appears. The configuration screens are not visible. Repeat the procedure above to unlock the configuration screens.

3.3.4 Language Screen

The *Language* screen provides the ability to display English, German, French, Portuguese, and Spanish on the front panel.



To change the display language:

1. Press .
2. Press  or  to select the desired language.
3. Press .

The screen automatically displays the configured language.

4 Operation Screens

This chapter shows you how to:

- use the Guidance Operation screens
- use the Utility screens

Trimble recommends that you read through this chapter to learn basic skills before attempting to calculate field area and measure line lengths. Figure 4-1 maps the operation screens.







Figure 4-1 Operation Screen Hierarchy

4.1 Utility Screens

To view the Utility screens, press  from the *Home* screen until the *Operations* screen appears. Press . Press  until the *Utility* screen appears.



4.1.1 Area Calculation

Figure 4-2 explains the following *Area Calculation* screen.









Figure 4-2 Area Calculation Screen

Table 4-1 describes the Area Calculation functions.

Table 4-1 Area Calculation Functions

Value	Description
Add	Adds area points
Del	Deletes last area points
CLR	Clears all area points. Use before beginning a new field.

To change the Delete/Add/Clear function:

1. Press .
The cursor flashes.
2. Press  or  until the option you desire is visible.
3. Press  to accept the change.

4.1.2 Adjusted Area

The *Adjusted Area* screen displays an area offset by 1/2 the swath width setting in the *Guidance Configuration* menu.
(See *AgGPS Parallel Swathing Option Manual*.)



Note – The *Adjusted Area* screen is only used when operating the AgGPS Parallel Swathing Option.

When using the parallel swathing option, obtain an accurate field area by driving the field perimeter. Place the end of the applicator boom over the field boundary. Entered area points are offset to the Boom end. The resulting area is displayed here, in the *Adjusted Area* screen.

4.1.3 Path Length

The *Path Length* screen displays the length traveled between entered area points.

A screenshot of a handheld device screen with a light gray background and a dark gray border. The text "Path Length" is displayed at the top in a monospaced font. Below it, the number "0" is followed by the word "meters" on the same line.

As area points are added, the path length increases.

4.1.4 Perimeter

The *Perimeter* screen displays the perimeter of entered area points. A line between the last and first entered area point is used to close the area.

A screenshot of a handheld device screen with a light gray background and a dark gray border. The text "Perimeter" is displayed at the top in a monospaced font. Below it, the number "0" is followed by the word "meters" on the same line.

As area points are added, the perimeter increases.

4.1.5 Segment Length

The *Segment Length* screen displays the length between the last two entered area points.

A screenshot of a handheld device screen with a light gray background and a dark gray border. The text "Segment Length" is displayed at the top in a monospaced font. Below it, the number "0" is followed by the word "meters" on the same line.


As area points are added, the last segment length is calculated.

5 Status

This chapter shows you how to use the GPS, DGPS, Receiver, and CAN status screens.



Trimble recommends that you read through this chapter when troubleshooting and verifying the status of the AgGPS receiver.

Figure 5-1 maps the AgGPS status screens.

**Figure 5-1 Status Screen Hierarchy**

To view the status screens, press ► from the *Home* screen until the *Status* screen appears. Press ▼.

5.1 GPS Status Screens

To view the status of the GPS information, press  until *GPS Status* appears. Press  to view the available screens.



5.1.1 Location

Figure 5-2 explains the following *Location* screen.




Figure 5-2 Location

Table 5-1 Types of Recorded Positions

Value	Description
D	Differential GPS
S	Searching for DGPS satellites. Current position is old.
G	Autonomous GPS
-	No valid satellites are tracked.

Table 5-2 Position Dimensions

Value	Description
2	Two-dimensional position
3	Three-dimensional position

5.1.2 Altitude

Figure 5-3 explains the following *Altitude* screen.




Figure 5-3 Altitude

5.1.3 Velocity

Figure 5-4 explains the following *Velocity* screen.




Figure 5-4 **Velocity**

Table 5-3 **Heading Values**

Value	Description
0°	North
90°	East
180°	South
270°	West

5.1.4 GPS Satellite Information

Figure 5-5 explains the following *GPS Satellite Information* screen.

←	Ch	Sv	S/N	E1	Azm
	1	17	55	49	274




Figure 5-5 GPS Satellite Information

A channel may contain incomplete satellite information.
Table 5-4 explains the messages that could appear on the screen.

Table 5-4 Incomplete Satellite Data Messages

Ch Sv S/N EI Azm	Meaning
1 17 35 -- --	No data yet received from the satellite.
1 17 Searching	Searching for but not tracking satellite.
1 Idle	No satellite available to track.

5.1.5 DOPs

Figure 5-6 explains the following *DOPs* screen.






Figure 5-6 DOPs

When viewing DOP information, lower numbers are better. For a description see Position Dilution of Precision (PDOP), page 1-5.

Press  to return to the main menu.

5.2 Beacon DGPS Status (Beacon Mode Only)



Note – If using an AgGPS 132, press + until the *Home* screen becomes visible. Press and hold until B appears in lower left corner. This ensures you are in beacon mode.

To view the status of the DGPS information, press from the *Status* screen. Press until *DGPS Status* appears. Press to move through each screen.



5.2.1 Beacon Status

Figure 5-7 explains the following *Beacon Status* screen.




Figure 5-7 Beacon Status



Note – When searching for a beacon signal, the bottom line display switches between Idle, Wideband FFT, Tracking, Searching, and Disabled Messages.

5.2.2 Alternate Beacon

Figure 5-8 explains the following *Alternate Beacon* screen.




Figure 5-8 **Alternate Beacon**

5.2.3 DGPS Data Source

Figure 5-9 explains the following *DGPS Data Source* screen.

DGPS Data Source			
Bcn	0	Stn	268




Figure 5-9 DGPS Data Source

5.2.4 DGPS Age

Figure 5-10 explains the following *DGPS Age* screen.












Figure 5-10 DGPS Age

Press  to return to the main menu.

5.3 Satellite DGPS Status (AgGPS 132 in Satellite Mode Only)



Note – Press  +  to return to the *Home* screen. Press  until an *S* appears in lower-left corner. This ensures you are in satellite mode.

To view the status of the DGPS information, press  until the *Status* screen appears. Press . Press  until *DGPS Status* appears. Press  to move through each screen.



DGPS Screens
Press  to Enter

5.3.1 Satellite Differential Status

Figure 5-11 explains the following *Satellite Differential Status* screen.




Figure 5-11 Satellite Differential Status

5.3.2 Service Provider ID

Figure 5-12 explains the following *Service Provider ID* screen.




Figure 5-12 Service Provider ID

5.3.3 DGPS Data Source

Figure 5-13 explains the following *DGPS Data Source* screen.




Figure 5-13 DGPS Data Source

5.3.4 DGPS Age

Figure 5-14 explains the following *DGPS Age* screen.



```
Age of DGPS  1.0
Age of Sync   3.0
```




Figure 5-14 DGPS Age

5.3.5 Racal-LandStar Service Info

Table 5-5 describes options available in the following *Racal-LandStar Service Info* screen.




Press  to move through the options.

Table 5-5 Racal-LandStar Subscription Options

Option	Meaning
User Code XXXXX	Racal-LandStar user code. This number is needed when subscribing to Racal-LandStar service.
Access Unknown	Subscription status is unknown.
User Enabled	Subscription is active.
User Disabled	Subscription is inactive.
Version XX.XX	Racal-LandStar decoder software version.

For subscription installation information, see Appendix F, Activating a Satellite DGPS Service.

5.3.6 OmniSTAR Service Info

Table 5-6 describes the options available in the following *OmniSTAR Service Info* screen.




Press  to move through the options.

Table 5-6 OmniSTAR Subscription Options


Option	Meaning
Init Decoder	OmniSTAR decoder is initializing.
Decoder Ready 1-4	Decoder is ready, but DGPS data not yet received.
Access Confirmed	Access confirmed, but no data yet.
Received Data	System providing DGPS corrections.
No Recent Data	Data has been received in the past, but not in the last 10 seconds.
No Decoder Available	OmniSTAR decoder not available or is not operating correctly.
Access Unknown	No access to OmniSTAR DGPS.
Stop XX/XX/XX	End date of OmniSTAR DGPS subscription.


For subscription installation information, see Appendix F, Activating a Satellite DGPS Service.

5.3.7 Service ID and Initialization Vector (IV)




The *Service ID and Initialization Vector (IV)* screen is shown below:




Press  to cycle through the AgGPS Service ID and IV database. This database contains information about supported DGPS services. You can add to this database in configuration if you require a service not automatically listed.

Press  to return to the main menu.

5.4 Receiver Status

From the *Status* screen, press . Press  to display the *Receiver Status* screen. Use  to move through the screens.



5.4.1 Time Screen

Figure 5-15 explains the following *Time* screen.




Figure 5-15 Time

5.4.2 Date and GPS Week

Figure 5-16 explains the following *Date and GPS Week* screen.




Figure 5-16 Date and GPS Week

5.4.3 Receiver Serial Number

Figure 5-17 explains the following *Receiver Serial Number* screen.





Figure 5-17 Receiver Serial Number

5.4.4 Firmware Version and Release Date

Figure 5-18 explains the following
Firmware Version and Release Date screen.






Figure 5-18 Firmware Version and Date

5.4.5 Receiver Options

Table 5-7 describes options available in the *Receiver Options* screen.




Press  to cycle through the available options.

Table 5-7 Receiver Options

Option	Screen Appearance	Description
Fast Rate	Fast Rate (U) 1 Hz	1 Hz fix only.
	Fast Rate (A) 1 Hz	Fast Rate available but currently tracking at 1Hz.
	Fast Rate (U) 5 Hz	Fast Rate is not activated, but the system is outputting LBAR messages to the AgGPS Parallel Swathing Option LightBar at 5 Hz.
	Fast Rate (A) 10 Hz	Operating in Fast Rate mode.
Base Stn	Base Station (A) On	Operating in base mode.
	Base Station (A) Off	Base station option is available, but Off.
	Base Station (U) Off	Base station option unavailable.
Everest	Everest MPR (U)	Everest option is unavailable.
	Everest MPR (A)	Everest option is On.
Parallel Swathing Option	Guidance (A) Off	Parallel Swathing option available, but Off.
	Guidance (A) On	Parallel Swathing option operating.
	Guidance (U)	Parallel Swathing option unavailable.
Providers	ALL	OmniSTAR and Racal Corrections available.
	OmniSTAR	Only OmniSTAR corrections available.
	Racal	Only Racal corrections available.
D&E	D&E Sub 2/1/99	Expiration date for CSI/D&E encrypted beacon service.

For option descriptions, see Chapter 1, Overview.

5.4.6 System Voltages

Figure 5-19 explains the following *System Voltages* screen.





Figure 5-19 System Voltages

Press  to return to the main menu.

5.4.7 Incident Report

The *Incident Report* screen is shown below.





Incident None


N/A

If a problem occurs with the receiver, a diagnostic code appears. This code provide information to Trimble technical support.


5.5 CAN Status


From the *Status* screen, press .

Press  to display the *CAN Status* screen.



CAN Status

Press  to Enter

Use  to move through the screens.



Note – The *CAN Status* screens are used only when operating the CAN Bus. The CAN Bus is an optional wiring configuration that replaces the traditional serial connection. For more information, contact your local dealer.

5.5.1 Channel A Status

The *Channel A Status* screen provides connection status information when the CAN Bus is connected to receiver Port A.





Figure 5-20 Channel A Status

Table 5-8 Channel Status

Option	Description
None	No address has been claimed.
OK	Address successfully claimed.
Trying	Address claim in process.
Failed	The receiver was unable to establish an address on the CAN Bus.

5.5.2 Channel B Status

The *Channel B* status screen provides connection status information when the CAN Bus is connected to receiver port A.

The *Channel B* status screen operates exactly like the *Channel A* status screen. See section 5.5.1.

6 Configuring the AgGPS 124 and 132 Receiver

This chapter shows you how to configure your AgGPS receiver:

- for data collection applications
- to operate as a base station

We recommend you read through this chapter before attempting to configure your AgGPS receiver.

6.1 Configuring the AgGPS Receiver

The GPS and beacon operating parameters are set to predefined values. These settings are suitable for many different applications and allow the AgGPS receiver to be used immediately after installation. You can use the front panel to change configuration parameters for special applications and, if operating an AgGPS 132 receiver, activate satellite differential services.

Figure 6-1 maps the AgGPS receiver configuration screens.




Figure 6-1 Configuration Screen Hierarchy

6.1.1 Using the Keypad to Change Configuration Settings

In the configuration menus, the keypad contains more functions than when navigating through the *Status* screens. For more information, see Viewing Status Screens, page 3-3.

To use a typical configuration screen:


1. On the main menu, move to a *Configuration* screen and press **▼**.
2. Press **▼** to cycle through the *Configuration* screens.
3. Press **>** to activate the configurable options.


The first setting option flashes.


4. Press **▲** or **▼** to cycle through the available settings. If there are multiple settings on a single screen, press **>** to activate the next setting.
5. When all settings are complete, press **⏏**.
6. Press **▼** to display the next *Configuration* screen.

6.2 GPS Configuration

GPS configuration screens determine how the AgGPS receiver computes position data. To display the main menu *GPS Configuration* screen:

1. Display the *Home* screen.
2. Press  until the main menu *GPS Config* screen appears.



3. Press  to cycle through the available screens.

GPS configuration screens are described in the following sections.






Tip – The GPS Configuration default settings are ideal for most applications.

6.2.1 Restore Defaults

The *Restore Defaults* screen returns the GPS mode settings to default. This screen is particularly valuable when troubleshooting. An incorrect GPS configuration can prevent the output of GPS positions. Restoring defaults eliminates GPS configuration errors.



To restore GPS defaults:

1. Press .
2. Press  until yes is displayed on the front panel.
3. Press .

The defaults are restored.

6.2.2 GPS Mode

The GPS mode setting determines if two-dimensional or three-dimensional position data is output. Three-dimensional positions contain latitude, longitude, altitude, and time. Two-dimensional positions contain latitude, longitude, and time. When submeter accuracy is required, Manual 3D is the recommended setting. When continuous data is more important than accuracy, Auto 2D/3D is recommended. The *GPS Mode* screen is shown below:




Table 6-1 describes the GPS Mode settings.

Table 6-1 GPS Mode Settings


Setting	Description
Manual 2D	Three satellites are used to calculate 2-dimensional positions. The altitude computed at the last 3-dimensional position is used for all 2-dimensional positions. The altitude value may change slightly if it is inconsistent with the position values.
Manual 3D	Four or more satellites are used to calculate 3-dimensional positions. This is the most accurate setting, but only yields positions when 4 or more satellites are visible.
Auto 2D/3D	Four or more satellites are used to calculate 3-dimensional positions when possible. When only three satellites are available or PDOP exceeds a user defined mask, 2-dimensional positions are output. The altitude computed at the last 3-dimensional position is used for all 2-dimensional positions.



Caution – Inaccurate altitude values have a significant impact on 2-dimensional position accuracy. As a rule of thumb, every meter (3 feet) of error in the altitude component is likely to cause at least three meters (9 feet) of horizontal error.

6.2.3 System Masks

System masks filter poor satellite data that reduces position accuracy. The AMU mask filters data based on signal to noise ratio. The Elevation mask determines the lowest elevation, in degrees, at which the AgGPS receiver uses a GPS satellite. The *System Masks* screen is shown below:



To set the system masks:

1. Press **>** to activate the AMU mask.

When collecting data under a canopy, the recommended mask setting is 6. When working in open fields you can reduce the setting to 2. If the signal-to-noise ratio for a particular GPS satellite falls below the mask value, the satellite is not used when computing a position.

2. Press **>** to activate the Elevation mask. The recommended setting for highest accuracy is 15°. There is a trade-off between accuracy and continuous operation. Lower the elevation mask to ensure continuous operation. The default is 8°.

3. Press **←** to save your settings.



Note – The AMU mask can be set from 0 to 10 and the Elevation mask from 0° to 90°.

6.2.4 PDOP Settings

GPS data with high PDOPs yield poor position accuracy. PDOP settings determine how high the PDOP can rise before the receiver stops providing position data or, if in Auto 2D/3D mode, switches to 2-dimensional positions. The *PDOP Settings* screen is shown below:



Table 4-2 describes the PDOP Mask and 2D-3D settings.

Table 6-2 PDOP Mask and 2D-3D Settings

Setting	Description
Mask	GPS positions are not output when the PDOP values rise above the PDOP mask. A low mask (below 8) ensures quality positions are output, but when PDOP rises, no data is available. A high mask (8 and above) can increase the amount of data output, but some data may be less accurate. Raise the PDOP mask when accuracy is less important than continuous data.
2D-3D	Two-dimensional positions are output when PDOP rises above the 2D-3D setting. This setting is only valid if Auto 2D/3D is selected as the position mode.



Note – The PDOP mask and PDOP switch can be set from 0 to 99.

6.2.5 PV Filter and Position Rate

The PV Filter and Position Rate settings affect the data quality collected from a moving antenna. The *PV Filter and Pos Rate* screen is shown below:



Table 6-3 describes the PV Filter and Position Rate setting.

Table 6-3 PV Filter and Position Rate Settings

Setting	Option	Description
PV Filter		Smooths position data when the antenna is moving and attempts to reduce the effects of position disturbances, which include reflected signals and small outages of DGPS corrections. The recommended setting for PV filter is D+S.
	D+S	This setting is ideal for Dynamic and Static applications. That is, applications where the antenna is stationary or moving at greater than 0.1 m/s. (3 ft. per second).
	DYN	This setting is ideal for slow vehicles where the antenna moves less than 0.1 m/s (3 ft. per second) or 0.2 m.p.h.
	OFF	No position filtering.
Pos Rate		Determines how often GPS positions are updated. The standard rate is 1 Hertz (1 Hz). If the Fast Rate option was purchased, a 10 Hz rate is available. A 10 Hz setting updates the GPS position 10 times a second. 1 Hz updates the position once every second. The Fast Rate option is ideal for applications where the antenna moves at high velocity.



Note – The Fast Rate option enables 10 Hz data output. When using the Parallel Swathing Option, up to 5 Hz is available.

6.2.6 Dynamic Mode

The Dynamics Code field informs the receiver of your usual operation mode. The *Dynamic Mode* screen is shown below:



```
CFG: Dynamic Mode
Type: Land
```

A correct Dynamics Code setting reduces the initial satellite acquisition time. There are four available dynamic codes: Static, Land, Sea, and Air. The recommended setting for most agriculture applications is Land. When operating in a plane or helicopter, choose Air.



Note – If you configure the Dynamics code incorrectly, you may notice a slightly degraded acquisition and reacquisition of satellite signals.

6.3 DGPS Configuration


DGPS Configuration screens determine which differential source the AgGPS 132 receiver uses. When using an AgGPS 124, only Beacon screens are available.

To display the main menu *DGPS Configuration* screen:

1. Press  until the *DGPS Config* screen appears.



```
Config DGPS
Press [left arrow] to Enter
```

2. Press  to cycle through the screens. DGPS Configuration screens are described in the following sections.

6.3.1 DGPS Mode

DGPS mode determines if corrections are applied to every output position. This configuration setting is crucial when DGPS accurate data is required. The *DGPS Mode* screen is shown below:



Table 6-4 describes the DGPS mode settings.

Table 6-4 DGPS Mode Settings

Setting	Description
DGPS Only	Outputs only GPS positions that are real-time corrected. Assures the best accuracy possible; but when the DGPS source is lost, no data is output.
DGPS Auto On/Off	DGPS positions are output when available. When the DGPS source is lost, autonomous positions are generated.
DGPS Manual Off	Outputs only autonomous positions. Positions are only accurate up to 100 meters.

6.3.2 DGPS Correction Age

The DGPS Correction Age setting determines the maximum age of a differential correction to be applied. If the most recent correction is older than the maximum age setting, no differential correction is applied.

```
CFG:  DGPS Corr Age
30 second limit
```

The default setting is 30 seconds.



Warning – The lower the setting the more likely a loss of DGPS will occur. The maximum setting is 60 seconds.

6.3.3 DGPS Source (AgGPS 132 only)

When using an AgGPS 132 receiver, the DGPS Source setting determines whether beacon or satellite differential corrections are applied. The AgGPS 132 receiver defaults to beacon differential. The *DGPS Source* screen is shown below:

```
CFG:  DGPS Source
Beacon Only
```

Table 6-5 describes the DGPS source settings.

Table 6-5 DGPS Source Settings

Setting	Description
Beacon Only	Beacon DGPS corrections are used.
Satellite Only	Satellite DGPS corrections are used (subscription must be activated to receive data).

6.3.4 Beacon Mode

This setting determines which radiobeacon the AgGPS receiver chooses when operating in Beacon Mode. The Beacon Mode setting is important when more than one beacon is available in your operating area. The *Beacon Mode* screen is shown below:



Table 6-6 describes the Beacon Mode settings.

Table 6-6 Beacon Mode Settings

Setting	Description
Manual Frequency	Uses corrections from the beacon broadcasting at a user-defined location.
Auto Range	Uses corrections from the closest beacon.
Auto Power	Uses corrections from the strongest beacon signal.
Disabled	Disables beacon DGPS receiver.

6.3.5 EZ Beacon 0

The *EZ Beacon 0* screen enables manual configuration of the primary beacon.



Note – The *EZ Beacon* screen is only necessary when manual frequency is selected as the Beacon Mode.

The beacon selected provides differential corrections. If this beacon becomes inoperable, the receiver defaults to the alternate beacon. (See Section 6.3.6.)



```
CFG: EZ Bcn 0:38 km
Pigeon Point
```

To manually select a beacon:

1. Press .

The cursor flashes.
2. Press or to scroll through the available beacons.



Note – Beacons within 800 km (approximately 500 miles) from the last position collected are visible.



Tip – Beacon distance from the last collected position is shown in the upper right corner of the screen. If you know of a local beacon that is not included in the receiver database, use the manual frequency screen to configure. (See Section 6.3.7, Manual Beacon Frequencies.)

3. Press to accept the desired beacon.




Note – The receiver must record a position before the EZ Beacon selection can be used. If no position has been collected or if no

beacons are available within 800 km, the screen reads:
No Known Beacon.

6.3.6 EZ Beacon 1

The *EZ Beacon 1* screen enables manual configuration of the alternate or secondary beacon.



CFG: EZ Bcn1:230 km
Chico

The *EZ Beacon 1* screen is similar to the *EZ Beacon 0* screen. See Section 6.3.5, EZ Beacon 0, for operating instructions.

6.3.7 Manual Beacon Frequencies



Tip – This screen is only used when the beacon mode is set to manual frequency and the local beacon is not in the receiver database visible on the EZ Beacon screens (see Section 6.3.5 and Section 6.3.6).

Manual beacon frequencies can be defined when the Beacon Mode is set to Manual Frequency. The AgGPS receiver contains two beacon channels. If there are multiple beacons in your area, set a frequency for each channel. If the primary beacon, Channel 0, is not available, the AgGPS receiver uses the secondary beacon, Channel 1. The *Manual Beacon Freqs* screen is shown below:



To configure manual beacon frequencies:


1. Press **>**.
The first configurable number flashes.
2. Press **▲** or **▼** to change the value.
3. Press **>** to highlight the next configurable number.
4. Continue until the proper frequencies are set, then press **↵**.

For a listing of local beacon frequencies, contact your national coast guard. In the USA, a beacon frequency list is available on the internet at WWW.NAVCEN.USCG.MIL.

6.3.8 Easy Satellite DGPS Configuration (AgGPS 132 Only)






The *Easy Satellite DGPS Configuration* screen automatically sets the satellite frequency and baud rate based on the location specified.

Enter your location and the receiver knows what frequency and baud rate to use.



```
CFG: EZ Sat: XXXXX
N. America central
```

When you obtain your satellite subscription, the service provider tells you which location to choose. To enter the provider and select the desired location:

1. Press .
2. Press  until your provider is listed.
3. Press .
4. Press  until your location is displayed.
5. Press  to accept and save.

6.3.9 Satellite Frequency (AgGPS 132 Only)



Tip – The *Satellite Frequency* and *Satellite Baud* screens are only used when the satellite frequency is not found under the *Easy Satellite DGPS Configuration* screen. This can occur when the DGPS provider changes frequency or baud rate after the release of the receiver firmware.

To apply corrections from a satellite differential service, you can manually enter the appropriate satellite frequency. Change the satellite frequency *only* when instructed by the DGPS provider. The *Satellite Freq* screen is shown below:

```
CFG: Satellite Freq
1556.2550 MHz
```

To set the differential service satellite frequency:

1. Press **>**.
The first configurable number flashes.
2. Press **▲** or **▼** to change the value.
3. Press **>** to highlight the next configurable number.
4. Continue until the proper frequency is set, then press **↵**.

The satellite frequency depends on your geographic location and differential service provider. For a listing of local satellite frequencies, contact your differential provider.

6.3.10 Satellite Baud

The satellite baud must match the output rate set by your differential provider. The satellite baud screen is shown below.



```
CFG: Satellite Baud  
  
1200 bps
```

Available baud rates are 600, 1200, and 2400.

6.3.11 OmniSTAR Activation

This setting contains a 24-digit OmniSTAR satellite differential service activation code. The *Omni** screen is shown below.



```
CFG:Omni* 00000000  
  
000000000000000000
```

To activate the OmniSTAR satellite differential service, see Appendix F.



Note – If an incorrect number (such as all zeros) is input, retry using the correct activation code. Incorrect codes have no effect on receiver operations.

6.3.12 Racal Solution

In some locations, Racal network DGPS solutions are not available. In these locations the corrections can be received from the nearest reference station. The *Racal Stations* screen is shown below:



```
CFG: Racal Stns
Use Network Stn
```

Table 6-7 describes the Racal Station settings.

Table 6-7 Racal Station Settings

Setting	Description
Use Network Stn	Uses corrections from the Racal Network. These corrections are usually more accurate than from a single station.
Use Closest Stn	Uses corrections from the closest reference station. These solutions are necessary if you are located outside the network range.


6.4 Configuring Port Parameters



Note – Port A and B can simultaneously communicate in both RS232 and CAN. The port parameter screens configure RS232 messages. If using CAN, see Section 6.5, Configuring CAN Parameters.


Ports A and B must be configured to make sure the proper data type is input and output from the AgGPS receiver. The configuration of Port A and Port B is identical; therefore, only Port A is discussed in this chapter.

To display the *Port A Configuration* screen:

1. Display the main menu.
2. Press  until the *Port A Configuration* screen appears.




```
Config Port A
Press [down arrow key] to Enter
```

3. Press  to cycle through the screens. *Port A configuration* screens are described in the following sections.

6.4.1 Setting the Port Input Parameters

Port input parameters are important when communicating with the AgGPS LightBar and other external devices. The *Port-A Input* screen is shown below:



```
CFG: Port-A in
TSIP 9600 8-0-1
```

Table 6-8 describes the Port input parameter settings.

Table 6-8 Port Input Parameter Settings

Setting	Description
None	Nothing is input.
TEXTB	ASCII data from an external device, such as a chlorophyll meter, can be input on Port A, merged with NMEA GPS data, and output on Port B. The incoming data must be limited to 66 ASCII characters and must be terminated by a carriage return and line feed (hex characters 0x0D 0x0A). The NMEA string outputs as \$PTNLAG001,<up to 66 ASCII characters>*<2 digit checksum><CR><LF>. To output the combined NMEA string, NMEA must be selected as the output protocol on Port B.
TEXTA	See the description for the TEXTB setting. TEXTA inputs on Port A, not Port B.
RTCM	Inputs RTCM data from an external DGPS device, such as an FM pager.
TSIP	Inputs TSIP data packets from the port when using the optional TSIP Talker software.
LBAR	Inputs data from the AgGPS LightBar. This setting is required when using the AgGPS Parallel Swathing Option.

The remaining settings configure baud rate, data bits, stop bits, and parity. The defaults are 9600, 8-O-1.

6.4.2 Setting the Port Output Parameter

Output parameters define the data type transmitted from the AgGPS receiver. Output settings are important when sending data to external devices such as a yield monitor or guidance lightbar.

The *Port A Output* screen is shown below:




Table 6-9 describes the Port Output Parameter settings.

Table 6-9 Port Output Parameter Settings


Setting	Description
None	Nothing is output.
RTCM E	Outputs RTCM data generated from an external source such as a radiobeacon, or satellite differential system. This option is sometimes referred to as bent pipe functionality.
RTCM I	Outputs RTCM data generated by a AgGPS receiver operating in base mode. For information about operating in Base mode, see Base Station Configuration, page 6-29.
NMEA	Outputs your selection of NMEA messages (see NMEA 1 Settings, page 6-22 and NMEA 2 Settings, page 6-23).
TSIP	Outputs TSIP data. This setting is required if you are outputting TSIP packets using the optional TSIP Talker software
LBAR	Outputs data to the AgGPS LightBar. This setting is required when operating the AgGPS Parallel Swathing Option.
TSIP R	Outputs RTCM data within a TSIP string. For more information, see the <i>TSIP Reference</i> manual.

The remaining settings configure baud rate, data bits, stop bits, and parity. The defaults are 9600, 8-O-1.

6.4.3 NMEA 1 Settings

When NMEA data is selected as the port output setting, you can change the selection of NMEA messages output by the receiver. The default messages are GGA, GSA, VTG, and RMC.

The Port A *NMEA-1* screen is shown below:



```
CFG: NMEA-1 GGA all
VTG esv GSA zda
```

To change the NMEA messages output:


1. Press **>**. The first three-letter NMEA message type flashes.
2. Press **^** or **v** to change the capitalization of the NMEA message type. When capitalized, the NMEA message is output. Lower case NMEA message types are not output.
3. Capitalize the NMEA message(s) to be output, and press **←** when you are finished.



Note – More NMEA data types are available on the Port A and Port B *NMEA-2* and *NMEA-3* screens.

6.4.4 NMEA 2 Settings

The settings on the Port A *NMEA-2* screen are extensions of the options found on the Port A *NMEA-1* screen. Three NMEA screens are required to present all of the NMEA options. Capitalized NMEA data types on both the *NMEA-1* and *NMEA-2* and *NMEA-3* screens are output. The Port A *NMEA-2* screen is shown below:



```
CFG: NMEA-2 RMC mss  
ptnlid ptnlde
```

6.4.5 NMEA 3 Settings

The settings on the Port A *NMEA-3* screen are extensions of the options found on the Port A *NMEA-1* and *NMEA-2* screens. Capitalized NMEA data types on each NMEA screen are output. The Port A *NMEA-3* screen is shown below:



```
CFG: NMEA-3 ers est  
ptnlsm ptnlsek
```




Tip – For detailed information about content and structure of NMEA messages, see Appendix D.

6.4.6 Message Rate

This setting can be used to vary the NMEA and TSIP output rate. For example, if the parallel swathing option is purchased, lightbar data is output at a rate of 5 times per second (5 Hz). Meanwhile, on the other port, NMEA or TSIP data can be output to a computer software package, yield monitor, variable rate controller, or other equipment at a slower rate.

The message rate screen is shown below:



```
CFG: NMEA out  ASAP
      TSIP out   ASAP
```

To modify the port output rate, select the NMEA or TSIP message and choose the required rate. ASAP equals the rate selected on the *PV Filter and Position Rate* screens. A setting of *1s* outputs a position each second.



Warning – No messages are output unless the message type is selected in the *Port Output* screen.


6.5 Configuring CAN Parameters




Note – Port A and B can simultaneously communicate in both RS232 and CAN. The CAN parameter screens are used to configure CAN messages. If using RS232, see Section 6.4, Configuring Port Parameters.

Ports A and B can be configured to ensure the AgGPS receiver secures an address on the CAN Bus. The configuration of Port A and Port B is identical; therefore, only CAN A is discussed in this chapter.

To display the *CAN A configuration* screen:


1. Display the main menu.
2. Press  until the *CAN A* configuration screen appears.



3. Press  to cycle through the screens. Port A configuration screens are described in the following sections.

6.5.1 CAN Rate

This setting is used to vary the CAN Rate or bits per second.

A screenshot of a device screen with a monospaced font. The text is arranged in two lines: the first line reads 'SFG: CAN A 250 kbs' and the second line reads 'J1939'.

```
SFG: CAN A 250 kbs  
J1939
```

The default speed is 250kbs. This conforms to the J1939 CAN specification.

6.5.2 Address

This setting is used to secure a receiver address on the CAN Bus.

A screenshot of a device screen with a monospaced font. The text is arranged in two lines: the first line reads 'SFG: J1939 Adr: 028' and the second line reads 'ECU: 000 Fnct: 000'.

```
SFG: J1939 Adr: 028  
ECU: 000 Fnct: 000
```

The recommended setting is 028. For more information, see the J1939 CAN specification.

6.5.3 Message Tape

This setting determines what data is included in the CAN message.

```
CFG: J1939 Mses-1
POS VEL TIME
```


The available messages are shown in Table 6-10:





Table 6-10 Messages

		J1939 Identifier	
Message	Description	PDU Format	PDU Specific
POS	GPS Position	254	243
VEL	Velocity	254	232
TIME	Time	254	230

Upper-case messages are included in the CAN message. Lower-case messages are not included in the CAN message.


To include or exclude individual messages:

1. Press .

The cursor flashes.
2. Press  or  to change the message status.
3. Press  to arrow to the next message.
4. Press  to save.

6.5.4 Interval

This setting determines the message interval or how often the selected messages are sent over the CAN Bus.



```
CFG: J1939 Interval  
1 second
```

The default rate in the receiver is 1 second. If outputting at 5 Hz, configure for 200 msec (milliseconds). If outputting at 10 Hz, configure for 100 msec.

6.6 Base Station Configuration

If you have not purchased the base station option, the following screens are not available.




Note – The base station configuration screens are only required when operating in base mode.


In base mode, the AgGPS receiver outputs RTCM data to a customer supplied radio solution. The radio then broadcasts the RTCM data to other receivers in the field.



The AgGPS is an ideal receiver to operate in base mode because its real-time capabilities allow a submeter reference position to be created in seconds. Set the receiver over an unknown location and allow it to calculate a real-time position(s) to be used as the reference position. Once a reference position is supplied, the AgGPS receiver can begin generating RTCM data.

Use base station configuration screens to create the base reference position, turn on base mode, and configure the AgGPS serial ports.

To display the main menu *Base Station Configuration* screen:

1. Display the main menu.
2. Press  until the *Base Stn Config* screen appears.




3. Press . Press  to cycle through the screens.


6.6.1 Base Location

The *Base Location* screen is used to view and set the reference station coordinates. The *Base Location* screen is shown below:



```
CFG: Base Location
(Enter) View Location
```

To view the reference coordinates press .

Press  to cycle through latitude, longitude, and altitude screens.



Note – Reference coordinates are provided in Latitude/Longitude. The datum is WGS-84. Altitude is referenced to Mean Sea Level (MSL).

Set from here

To set the reference position from your current location:

1. Press **>**.
2. Press **↓**.

The screen reads:



3. Press **↵**.

The receiver automatically displays three screens showing your latitude, longitude, and altitude values. There are two options in each screen:

- To save the reference coordinate value, press **↵**.
 - To change the reference coordinate value, press **↑** or **↓**. Move to the next value by pressing **>**. Press **↵** to save your changes.
4. After pressing **↵** to accept the altitude value, the receiver asks whether or not to accept the new position. There are two options:
 - To accept the position, press **↵**.
 - To reject the position, press **↑** or **↓**. Then press **↵**.

Edit

To edit the current reference position:

1. Press **>**.
2. Press **↓**.

The screen reads:



```
CFG: Base Location
Edit Base Pos
```

3. Press **↵**.



The receiver automatically displays three screens showing latitude, longitude, and altitude values. In each screen:

- Press **↑** or **↓** to change a value.
- Move to the next value by pressing **>**.
- Press **↵** to save your changes.


4. After pressing **↵** to accept changes to the altitude value screen, the receiver asks whether or not to accept the new position. There are two options:
 - To accept the position, press **↵**.
 - To reject the position, press **↑** or **↓**. Then press **↵**.

Set by averaging positions

To edit the current reference position by averaging 100 positions:

1. Press .
2. Press .

The screen reads:





```
CFG: Base Location
Set Firm Avg 100
```



Note – Determining the reference position by averaging 100 positions may provide slightly better accuracies than the Set From Here option.

3. Press .

The receiver begins averaging 100 positions. There are two options:

- Press  to cancel.
- Wait until 100 positions are collected.
Press  to accept the averaged position.


6.6.2 Enabling Base Mode

To operate the AgGPS receiver as a base station, the base mode must be configured *On*.



Tip – You cannot enable Base mode unless a reference position is set.

The following screen appears:



```
CFG: Base Station
Mode: Off
```

To enable base mode:

1. Press **>**.
2. To toggle between off and on, press **^** or **v**.
3. Press **←** to save the setting.



Note – In base mode, the receiver does not output positions through TSIP.

6.6.3 Port A Output

To output RTCM data, the port output setting must be configured. The following screen appears:



```
CFG: Port-A Out  
TSIP 9600 8-0-1
```

1. Press **>**.
2. Press **^** or **v** to select RTCMI (internally generated RTCM) as the output setting.
3. Press **>**.
4. Configure the baud, data bits, stop bits, and parity to match the radio connection.
5. Press **←**.



Tip – If the receiver is used for different applications, the port output parameters must be configured each time to make sure the proper data type is output.

6.6.4 Port B Output

Port A or B can be used to output RTCM data. If the radio link is connected to Port B, arrow to the Port B Output screen and follow the instructions provided in Port A Output, page 6-35. Substitute Port B for Port A.

7 Troubleshooting

This chapter covers frequently asked questions and troubleshooting techniques for the AgGPS 124 and 132 receiver. Trimble recommends you read through this chapter before calling technical support.

7.1 Increasing GPS Accuracy

The AgGPS receiver always gives the most accurate position under the current GPS, beacon, or satellite differential operating conditions. By manipulating various GPS masks, some satellite configurations are locked out, preventing less accurate positions from being computed. However, these changes can prevent positions from being output.

If your GPS application can tolerate occasional outages, then more accuracy is possible by changing the various GPS receiver parameters from their default values.

There are many GPS receiver parameters that affect accuracy:

- Elevation Mask

The default Elevation Mask is 8°. Raising this mask prevents the receiver from using some low elevation satellites, often a source of inaccurate positions.

- Signal Strength Mask

The default Signal Strength Mask is 6. Increasing the signal strength mask prevents the use of weaker GPS signals that contribute to inaccurate positions.

- PDOP Mask

The default PDOP Mask is 6. Lowering this mask ensures the receiver uses only satellite constellations that provide the highest accuracy.

- GPS Mode

The default GPS position mode is Auto 2D/3D. Three-dimensional positions are more accurate than two-dimensional positions, so changing the receiver to Manual 3D prevents 2D positions from being computed.

- DGPS Mode

The DGPS mode default setting is DGPS Auto/On/Off. Selecting DGPS Only, restricting the receiver to only output differential GPS positions, prevents autonomous (non-differential) positions from being computed.

A relatively uncontrolled source of position inaccuracy is multipath noise, caused by reflections of the GPS signals from nearby buildings and flat surfaces. For best accuracy, mount the GPS antenna so it has a clear view of the sky. Accuracy is best when operating away from buildings and trees.

7.2 Intermittent GPS Loss

When GPS lock is intermittent, the antenna cable may be disconnected. Check that all connections are secured properly. Protect the antenna cable/antenna connection with the coax tape seal. If the coax tape is not properly placed, water may enter the cable connection and cause intermittent loss of GPS satellite lock. If you do not have the coax tape, disconnect the cables and let them dry. Reconnect the antenna cable and apply coax tape.

If the antenna is connected properly, make sure that it is mounted on the highest point of the vehicle, so that no GPS signals are blocked. Depending on the orientation of the vehicle, the satellites and the possible obstruction, one or more satellites may be blocked. Sometimes blocking shows up when traveling one direction, but not while traveling other directions.

If the antenna seems fine, check the configuration masks. If the PDOP or SNR Masks are set to extreme levels, the receiver could possibly ignore valid satellite data. The default SNR Mask is 6. The default PDOP Mask is 6.

7.3 Power Lines and Strong Magnetic Fields

In North America, the energy from power lines is 60 Hz (50 Hz in Europe). The harmonic energy falls off rapidly as the frequency increases. Thus, power lines have very little effect on the GPS signal. However, noise radiation from power lines may cause interference to the beacon DGPS signal. The interference, if any, is usually localized, up to a half mile from the power line.

Strong magnetic fields have no effect on GPS signals. Some computers and other electric equipment radiate electromagnetic energy that can interfere with a GPS receiver or with the differential radiobeacon data link. If you suspect interference from a local magnetic field, move the antenna away from, or turn off the suspect electronics while observing the GPS receiver's readings.

7.4 Choosing an Antenna Location

The antenna must be mounted so that it has a clear view of the sky, on the center line of the vehicle, away from any sources of interference like electric motors. See Choosing a Location, page 2-5.

7.5 Checking for Antenna Cable Failure

To check the antenna cable for a short, use an ohmmeter. The resistance of a good cable between the inner and outer conductor is infinite and the resistance between each end of the cable, inner conductor to inner conductor, is zero.

If the cable checks out fine, but you are confident it is the cable causing the errors, move the cable and try again. Cables sometimes work only when bent in certain ways.

If the cable is defective, contact your local Trimble representative.

7.6 Why Beacon DGPS Works In Some Places But Not Others

The radio signals from the DGPS broadcast transmitters sometimes get blocked or encounter interference. For example, the range of the Coast Guard radio navigation beacon transmitters is 100 to 250 miles, depending on the strength of the transmitter and efficiency of the transmitting antenna. If you are outside of the range of these broadcasts or have local interference, for instance, from power lines, you may not receive the beacon DGPS corrections. High voltage power lines can be a severe source of noise, especially if there is a leaky insulator or other source of corona discharge.

During the night at longer distances from the beacon stations (150 to 300 miles), the beacon skywave (reflected off the ionosphere) can interfere with the ground wave beacon signal. This phenomenon of self-jamming at night may be a problem with stronger beacon stations.

7.7 Reducing Engine Noise

An unshielded ignition system can radiate enough noise to block reception of the beacon signal. To solve this problem, use resistor spark plug wires. Sometimes an alternator generates noise that interferes with the beacon. Use bypass capacitors, commonly available in automotive stores for cleaning up interference to CB and other radios. If the problem persists, engine components can be shielded with aluminum foil.

Before purchasing new engine parts, make sure that there is not a PC computer or power source near the AgGPS receiver. Some PCs and their power sources generate noise that is disruptive to the beacon signal.

7.8 Determining if the Beacon is Operable

In the USA, call 1-703-313-5900 for Coast Guard GPS support. Or use the web site at <http://www.navcen.uscg.mil/gps/status.txt> for the operational status of the beacon stations. For non-U.S. beacons, contact the local beacon provider.

7.9 Losing the Beacon Signal at Night

Some stations at about 170 to 230 miles are received during the day with good signal strengths. However, at night, a station jams itself because of the presence of sky waves. The sky wave in the day passes through the ionosphere and is lost in space, while at night the ionosphere becomes reflective and allows the sky wave to be received. The sky wave signal being received at the receiver causes deep fades when combined with the ground wave signal.

The only solution is to set the receiver to use a different beacon signal. The sky wave fading may last many minutes and constantly change as the ionosphere alters its height and reflectivity characteristics. The same phenomenon can be seen on the AM radio band when listening to distant stations.

7.10 Using the Optional TSIP Talker Software

Only a few of the special functions available with the TSIP Talker software can not be programmed on the AgGPS 124 or 132 front panel. The most important feature is the FFT display. This display is important when searching out noise sources that interfere with the reception of the beacon signal.

7.11 Why Satellite DGPS Works in Some Places But Not Others

Local canopy cover in the direction of the differential satellite can reduce the correction signal strength to unusable levels. Wet canopy reduces signals even more. The same local environmental factors that affect GPS signals, such as radar sets, microwave transmitters, and the like can interfere with the differential satellite signals.

Differential satellite signals are line-of-sight. This complicates the use of satellite corrections in mountainous regions, especially at higher latitudes when the satellite view angle is closer to the horizon.

7.12 Interfacing the Receiver With Other RTCM Sources

Use the power/data cable (P/N 32015), which allows separate RTCM input and NMEA output. The default baud for external RTCM input is 9600-N-8-1. The external source of RTCM overrides any beacon or satellite DGPS.

7.13 Verifying the RTCM Source is Outputting Messages

The vendor of the RTCM decoder usually has a PC program that decodes the RTCM messages. If this program is not available, then connect the AgGPS receiver to the external RTCM source and monitor the GGA NMEA message. If the DGPS Mode = 2, then the positions are being generated with RTCM corrections. Disconnect the external RTCM source and verify the DGPS Mode =1.

7.14 Verifying the Unit is Outputting NMEA Messages

Connect the AgGPS receiver to a PC with the Standard Data/Power Cable (P/N 30945) and use a Windows terminal program to view the NMEA messages. The default NMEA parameters are 4800-N-8-1. View the lat/long changes on your yield monitor.

7.15 Losing Configuration Settings When the Receiver is Powered Off

The AgGPS receiver configuration parameter settings are stored in battery-backed RAM (random access memory). The Lithium battery has a 10-year life span. You can assume the Lithium battery has failed when the receiver no longer retains configuration parameter setting changes.



Note – The receiver can continue to use the default configuration parameters, but does not retain any changes to the default settings after it is powered off.



Contact Trimble Navigation Customer Service or an Authorized Trimble Servicing Dealer to arrange for replacement of Lithium batteries.

7.16 The Receiver Front Bulges Out


The AgGPS receiver front panel may bulge if pressure inside the receiver is greater than outdoor air pressure. To reduce front panel bulge, loosen the screw to the left of Port A on the receiver back panel. When the pressure has been released, tighten the screw.

7.17 Restoring the Receiver to Factory Defaults

To restore the receiver configurations to factory defaults:

1. Turn the receiver off.
2. Simultaneously press  and .
3. Power the receiver.

The receiver asks if you want to “Clear BB Ram”.

4. Press the up or down arrow until the display reads yes.
5. Press .

The receiver returns to factory defaults. DGPS provider activation remains valid.

Troubleshooting Guides

System Hardware and Power Check Guide




Figure 7-1 System Hardware and Power Check Guide

GPS Reception Troubleshooting Guide

START HERE




Figure 7-2 GPS Reception Troubleshooting Guide

124/132 Operation Manual

START HERE

Beacon Troubleshooting Guide




Figure 7-4 Beacon Troubleshooting Guide

START HERE

Check the Home screen to verify GPS satellite reception. Are you receiving GPS satellites?

Yes
On the Home screen, you should see an "S" in the lower left corner, indicating the DGPS Mode is Satellite Only. If you see a "B" (Beacon mode), press **[Menu]** and hold for 5 seconds to switch from beacon to satellite mode.

Continue
Have you activated your receiver for the OmniSTAR subscription?

Yes
To set the correct OmniStar frequency from the Home screen, press **[>]** to Configuration. Press **[>]** then press **[>]** to DGPS Config. Press **[>]** until you see EZ Sat: Omni* or EZ Sat: Racal.

Continue
Press **[>]**, then press **[v]** until EZ Sat: Omni* is displayed. Press **[>]**, then press **[v]** until the desired satellite footprint, or geographic area, is displayed. Press **[v]** to select, then press **[v]** together three times to return to the Home screen.

No
Refer to the OmniSTAR Activation Tree to activate your subscription. If problems persist, contact the Trimble Technical Assistance Center.

OmniSTAR Troubleshooting Guide -- AgGPS 132 Only

Something appears to be interfering with the OmniSTAR signal. From the Home screen, press **[>]** to Status. Press **[v]** then press **[>]** to DGPS Status. Press **[v]** until you see Age of DGPS and Age of Sync. If Age of DGPS is approximately 10 or more and the Age of Sync > 3, something is jamming the OmniSTAR signal. Proceed with noise checks.

Continue
Press **[v]** again to check OmniSTAR status. Do you see either of the following two status messages: "Received Data" or "No Recent Data"?

Yes
The received or old data is not sufficient for good DGPS positioning. Contact OmniSTAR.

No
Is status message: Init Decoder (1-4), or Decoder Ready, or Access Confirmed?

Yes
You may be lacking a current OmniSTAR almanac. Set up your receiver and track satellites for 1-2 hours. If problem persists, contact the Trimble Technical Assistance Center.

No
Contact the Trimble Technical Assistance Center.

No
On the Home screen, check the strength of the received satellite signal. Is the S/N strong (approximately 6 or more)?

Yes
From the Home screen, press **[>]** to Status. Press **[v]**, then press **[>]** to DGPS Status. Press **[v]** to Omni* Srv Info screen, then press **[v]**. Do you see User Enabled?

No
Your system appears to be working properly now. If problems persist, contact the Trimble Technical Assistance Center.

Yes
Press **[v]** until you see Stop and a date. Is this date expired (past) or in the future?

Stop date expired
Refer to the OmniSTAR Activation Tree to activate your subscription. If problems persist, contact the Trimble Technical Assistance Center.

Stop date in the future
You may be lacking a current OmniSTAR almanac. Set up your receiver and track satellites for 1-2 hours. If problem persists, contact the Trimble Technical Assistance Center.

Continue
Turn off machine engine (but maintain power to GPS system). Wait 5 minutes. Now view Home screen to check GPS reception. Are you receiving at least 4 SVs?

Yes
Problem is unresolved. Contact the Trimble Technical Assistance Center.

No
Turn machine engine on and observe Home screen. Do satellites disappear?

Yes
There appears to be excessive engine noise. Review Section 1.5 for tips on reducing engine noise. If problems persist, contact the Trimble Technical Assistance Center.

No
You are receiving GPS satellites, but you are not receiving the OmniSTAR signal. Contact the Trimble Technical Assistance Center.

Figure 7-5 OmniSTAR Troubleshooting Guide

START HERE

Racal-LandStar Troubleshooting Guide -- AgGPS132 Only




Figure 7-6 Racal-LandStar Troubleshooting Guide

A Specifications

Table A-1 and Table A-2 list the physical characteristics of the AgGPS 124/132 receiver and the combined antenna.

Table A-1 AgGPS 124 and 132 Receiver

Size	14.5 cm W x 5.1 cm H x 19.5 cm D (5.7 in. W x 2.0 in. H x 7.7 in. D)
Weight	0.76 Kg (1.68 lb.)
Power	7 Watts (max), 10–32 VDC
Operating Temperature	–20°C to +65°C
Storage Temperature	–30°C to +80°C
Humidity	100% condensing, unit fully sealed
Casing	Dust-proof, waterproof, shock resistant

Table A-2 Combined Antenna

	124	132
Size	15.5 cm D x 10.8 cm H (6.1 in. D x 4.3 in. H)	15.5 cm D x 14.0 cm H (6.1 in. D x 5.5 in. H)
Weight	0.49 kg (1.08 lb.)	0.55 Kg (1.2 lb.)
Operating Temperature	−30°C to +65°C	−30°C to +65°C
Storage Temperature	−40°C to +80°C	−40°C to +80°C
Humidity	100% condensing, unit fully sealed	100% condensing, unit fully sealed
Casing	Dust-proof, waterproof, shock resistant	Dust-proof, waterproof, shock resistant

Table A-3 and Table A-4 list the performance characteristics of GPS and beacon channels.

Table A-3 GPS Channels

General	12-channel, parallel tracking L1 C/A code and carrier phase filtered measurements and multi-bit digitizer
Update Rate	1 Hz standard; 10 Hz optional
Differential Speed Accuracy	0.1 MPH (0.16 KPH)
Differential Position Accuracy	Less than 1 meter horizontal RMS; At least 5 satellites, PDOP < 4 and RTCM SC-104 standard format broadcast from Trimble 4000RSi or equivalent reference station
Time to First Fix	< 30 seconds, typical
NMEA Messages	ALM, GGA, [†] GLL, GSA, [†] GSV, MSS, RMC, [†] VTG, [†] ZDA
[†] By default, the AgGPS 124/132 receiver is configured to output GGA, GSA, VTG, and RMC messages.	

Table A-4 Beacon Channels

Frequency Range	283.5 kHz to 325.0 kHz
Channel Spacing	500 Hz
Beacon Modulation	50, 100, and 200 bits/second
Signal Strength	10 μ V/meter minimum
Dynamic Range	100 dB
Channel Selectivity	70 dB @ > 500 Hz offset
Frequency Offset	17 ppm maximum
3rd Order Intercept	+15 dBm @ RF input (min. AGC setting)
Beacon Acquisition Time	<5 seconds, typical
Operating Modes	Auto Power, Auto Range, and Manual

Table A-5 lists the characteristics of the L-Band Satellite Differential Correction Receiver with Multiple Vendor Support.

Table A-5 L-Band Satellite Differential Correction Receiver with Multiple Vendor Support (AgGPS 132 only)

Bit Error Rate	10^{-5} for Eb/N of >5.5 dB
Acquisition and Re-acquisition Time	<2 seconds, typical
Frequency Band	1525–1560 MHz
Channel Spacing	.5 kHz

B Receiver Defaults

Table B-1 lists the default settings for the AgGPS 124 and 132 receivers.

Table B-1 Receiver Defaults

DGPS Source	Beacon
Beacon Mode	Auto-range
Dynamics	Auto
Elevation Mask	8°
SNR Mask	6
PDOP Mask	12
PDOP Switch	8
DGPS Mode	Auto
DGPS Age Limit	30 sec
Pos Fix Rate	1 Hz

C Cables and Connectors

The tables in this appendix give pin-out information for the AgGPS 124 and 132 standard and optional cables. This information can be used to prepare special cables for interfacing the AgGPS 124 and 132 receivers with devices and instruments not supported by the *standard* and optional cables.

C.1 Port A and Port B Connectors

Table C-1 gives pin-out requirements for the AgGPS 124 and 132 Port A and Port B connectors.

Table C-1 Connector Pin-out for AgGPS 124 and 132 Port A and Port B

Pin	Port A Connector	Port B Connector
1	Event In	Event In
2	RS-232 B Out	RS-232 A Out
3	RS-232 B In	RS-232 A In
4	CAN Hi	CAN Hi
5	Ground	Ground
6	RTS Out	RTS Out
7	Power On/Off	Power On/Off
8	CTS In	CTS In
9	CAN Low	CAN Low
10	Battery +V	Battery +V
11	Battery -V	Battery -V
12	1 PPS Output	1 PPS Output

C.2 Standard Data/Power Cable

Table C-2 gives pin-out information for the Standard Data/Power Cable (P/N 30945).

Table C-2 Standard Data/Power Cable Pin-out (P/N 30945)

CONXALL Conn		Direction	DE9-F Conn			Power Leads	
12 Pin			7 Cond			2 Cond	
Pin	Signal		Pin	Color	Signal	Color	Signal
1	EVENT IN	←	4	—	DTR		
2	TXD	→	2	ORN	RXD		
3	RXD	←	3	BLU	TXD		
4	CHG CTRL	←	—	—	—		
5	SIG GND	↔	5	SHIELD	SIG GND		
6	RTS	→	8	YEL	RTS		
8	CTS	←	7	GRN	CTS		
9	CHARGE	→	—	—	—		
7	PWR ON	← jumper				RED	V+ IN
10	V+ IN						
11	V– IN	←				BLK	V– OUT
12	PPS	→	9	BLU	PPS		

C.3 Ag Leader Interface Cable

Table C-3 gives pin-out information for the Ag Leader Yield Monitor Interface Cable (P/N 30660).

Table C-3 Ag Leader Yield Monitor Cable Pin-out (P/N 30660)

CONXALL Connector		7-Wire Conductor		DE9-M Connector	
Pin	Signal	Color	Direction	Pin	Signal
1	EVENT IN	—	←	—	—
2	TX –	ORN	→	3	RXD (to Ag Leader device)
3	RX –	BLU	←	2	TXD (data not used by AgGPS 124 and 132 receiver)
4	CHG CTRL	—	←	—	—
5	SIG GND	SHIELD	↔	5	SIG GND
6	RTS	—	→	—	—
7	PWR ON	BRN	←	1	+5 (from Ag Leader device)
8	CTS	—	←	—	—
9	CHARGE	—	→	—	—
10	V+ IN	RED	←	4	+12 V (from Ag Leader device)
11	V– IN	BLK	←	6	PGND
12	PPS	—	→	—	—

C.4 Dual Data Interface Cable

Table C-4 gives pin-out information for the Dual Data Interface Cable (P/N 32015).

Table C-4 Dual Data Interface Cable Pin-out (P/N 32015)

CONXALL		Dir	DE9-M Conn		DE9-F Conn		Power
12 Pin			7 Cond		7 Cond		2 Cond
Pin	Signal		Pin	Signal	Pin	Signal	Signal
1	EVENT IN	←	—	—	—	—	
2	TX—	→			2	TXD	
3	RX—	←	2	RXD			
4	CHG CTRL	←	—	—	—	—	
5	SIG GND (Sheild)	↔	5	SIG GND	5	SIG GND	
6	TX+	→	—	—	—	—	
8	CTS	←	—	—	—	—	
9	CHARGE	→	—	—	—	—	
7	PWR ON	← jumper					V+ IN (Red)
10	V+ IN						
11	V— IN	←					V— OUT (Blk)
12	PPS	→	—	—	—	—	

C.5 Case AFS Cable

Table C-5 gives pin-out information for the Case AFS Dual Data Interface Cable (P/N 32609).

Table C-5 Case AFS Cable Pin-out (P/N 32609)

12-Pin CONXALL Conn		Direction	5-Pin MetroPack Conn	
Pin	Signal		Pin	Signal
2	NMEA OUT	→	D	RXD
3	YIELD DATA	←	B	TXD
5	DATA GND	↔	C	DATA GND
10	PWR IN	←	A	+12 VDC
11	PWR GND	←	E	PWR GND

C.6 John Deere GreenStar Data Cable

Table C-6 gives pin-out information for the John Deere GreenStar Data Cable (P/N 34189).

Table C-6 John Deere GreenStar Data Cable Pin-out (P/N 34189)

DE9-M Connector		Direction	Color	3-Pin Metropack Connector	
Pin	Signal			Pin	Signal
2	TXD	→	RED	A	RXD
3	RXD	←	BLK	B	TXD
5	GND	↔	BLU	C	GND

C.7 RDS Data Power Cable

Table C-7 gives pin-out information for the RDS power data cable (P/N 35142).

Table C-7 RDS Data Power Cable Pin-out (P/N 35142)

12-Pin CONXALL Connector			7 Cond Cable #1	DE9-M Connector (P2)	
Pin	Signal	Direction	Color	Pin	Signal
1	Event In	←			
2	TX– (232)	→	ORN	3	RXD
3	RX– (232)	←			
4	CHG CTRL	←			
5	SIG GND	↔	Shield	5	SIG GND
6	TX+ (422)	→			
7	PWR ON				
8	CTS	←			
9	CHARGE	→			
10	V+ IN	←	RED	8	V+
11	V– IN	←	BLK	7	PGND
12	PPS	→			

C.8 Windows CE Cable

Table C-8 gives pin-out information for the optional Windows CE cable (P/N 35283).

Table C-8 Windows CE Cable Pin-out (P/N 35283)

CONN P1			7 COND Cable #1	DE9-M CONN P2		CONN P3 CIG Lighter
Pin	Signal	Direction	Color	Pin	Signal	
1	Event In	←				
2	TX- (232)	→	ORN	3	RXD	
3	RX- (232)	←	BLUE	2	TXD	
4	CHG CTRL	←				
5	SIG GND	↔	SHIELD	5	SIG GND	
6	TX+ (422)	→				
7	PWER ON					
8	CTS	←				
9	CHARGE	→				
10	V+ IN	←				TIP
11	V- IN	←				BODY
12	PPS	→				

D NMEA-0183 Sentences

Trimble receivers can output a selection of NMEA-0183 sentences. NMEA-0183 sentences are normally generated and output to Port A, allowing the receiver to interface with external instruments. Only the NMEA-0183 standard and Trimble proprietary sentences configured using TSIP command packets are described here. Some Trimble products support additional NMEA-0183 standard sentences and Trimble proprietary sentences which cannot be configured using TSIP command packets. These are described separately in the receiver's operation manual.

D.1 NMEA-0183 Sentence Structure

NMEA-0183 sentences are strings of comma-delimited text. Figure D-1 shows the structure of an NMEA-0183 sentence.




Figure D-1 Sample ZDA Sentence Structure

Each NMEA sentence includes a sentence ID to distinguish the sentence from other NMEA sentences in the data stream. The actual data included in NMEA-0183 sentences is placed in fields. An NMEA sentence contains several fields, and each field is preceded by a comma character. The sample sentence in Figure D-1 contains six fields. The NMEA sentences include a checksum value which is useful for checking the integrity of the data included in the sentence.

The sentence structure of the sample ZDA sentence, shown below and the sentence fields are described in Table D-1.

\$GPZDA,220320.0,26,06,1997,00,00*52

Table D-1 Sample ZDA Sentence Structure

Field	Description
1	Time, in UTC. (220320.0 in the sample sentence)
2	Day, 01 to 31. (26 in the sample sentence)
3	Month, 01 to 12. (06 in the sample sentence)
4	Year. (1997 in the sample sentence)
5	Local time zone offset from GMT, 00 to ± 13 hours. (00 in the sample sentence)
6	Local time zone offset from GMT, minutes. Fields 5 and 6, together, yield the total offset. For example, if field 5 is '-5' and field 6 is '15', local time is 5 hours and 15 minutes earlier than GMT. (00 in the sample sentence)

The NMEA-0183 sentence examples in this chapter are presented in the format shown in Table D-1. The structure of each sample sentence is shown in the paragraphs preceding the sentence structure table.

The numbers in the Field column represent the sentence fields in left-to-right order. Field 1 is the first field following the first comma delimiter. In the sample sentence, field 1 contains the UTC Time value (220320.0). The last field in the sentence is preceded by the last comma in the sentence (00 in the sample sentence).

D.1.1 Symbols and Delimiters

All sentences conform to the NMEA-0183 Version 2.1 format. Symbols and delimiters are used to identify or separate the various kinds of data included in the sentence.

NMEA-0183 sentences always begin with a dollar sign character (\$) followed by a talker ID code and a sentence ID code. For the sample ZDA sentence, GP IS THE TALKER ID, AND ZDA is the sentence ID.

The string of comma delimited text immediately following the sentence ID code is composed of fields containing data. Each field is followed by a comma character (,). For the sample sentence, the data fields are shown below:

220320.0,26,06,1997,00,00

The first field contains the UTC time value (220320.0), the second field contains the Day value (26), and so on.

NMEA-0183 sentences include a checksum value which is preceded by an asterisk character (*). For more information about checksum values, see Checksum Values, page D-4.

NMEA-0183 sentences are always terminated with a carriage return and line feed. The carriage return and line feed pair marks the end of the sentence.

D.1.2 Checksum Values

Newer Trimble receivers conform to NMEA-0183 Version 2.1 which states that checksums are mandatory for all sentences. Checksum values are always included in output sentences, but are optional for input sentences.

Checksum values are used to verify the integrity of the data included in the sentence. The sample sentence, shown in Table D-1, includes a checksum value. An asterisk character (*) is used to delimit the last data field from the checksum value (52 in the sample sentence).

The checksum is the 8-bit exclusive OR of all characters in the sentence, between but not including the '\$' and '*' delimiters. Commas are also included. The hexadecimal result is converted to two ASCII characters (0-9, A-F). The most significant character appears first.

D.1.3 Field Formats

The data values included in fields meet the format specifications established for the NMEA-0183, Version 2.1 standard.

D.1.4 Null Fields

Null fields are included in some NMEA sentences when no data is available for a particular field. Null fields are empty and are usually reserved for transmitting data on a periodic or irregular basis. The comma delimiter for the Null field is immediately followed by the comma delimiter for the next field in the sentence string.

The inclusion of Null fields in a sentence is important because many NMEA sentences contain a fixed number of fields. NMEA sentence interpreters (software for processing NMEA sentences) expect to find a fixed number of fields in these sentences, and specific kinds of data in each field. The sentence processing software assumes that no data is available for a particular field when a Null field is encountered while interpreting a sentence.

D.1.5 Talker ID Codes

The Talker ID code identifies the source of the data (GPS, Loran C, Sounder, etc.). The NMEA-0183 standard defines 35 Talker ID codes. The Talker ID codes available for NMEA-0183 output from the most Trimble receivers are described in Table D-2.

Table D-2 Supported Talker ID Codes

Code	Description
GP	GPS
LG	Loran C/ GPS
LC	Loran C
II	Integrated Instrumentation

D.1.6 Latitude and Longitude Values

The latitude and longitude values included in NMEA sentences are presented in degrees, minutes, and decimal minutes. Latitude is presented as ddmm.mmmm in a single field, and longitude is presented as dddmm.mmmm in a single field. Within the field, degree values are in *dd* or *ddd* format, and minutes and fractions of minutes are in *mm.mmmm* format.

Latitude and longitude direction values (north, south, east, or west) are placed in a separate field. Direction is a single character: ‘N’, ‘S’, ‘E’, or ‘W’ for *North*, *South*, *East*, or *West*.

D.1.7 Time Values

Time values are in UTC (Universal Time Coordinated), and are inserted in sentence strings in *hhmmss.ss* format, where *hh* is hours (from 00–23), *mm* is minutes, and *ss.ss* is seconds and fractions of seconds.

D.1.8 Other Values

The NMEA-0183 standard established the format of the data included in sentence fields.

D.1.9 Reading NMEA String Format

When using NMEA strings, be aware that the strings can be of varying length, depending on how the receiver is configured. Comma delimited parsing is recommended.

D.2 NMEA Sentence Summary

Table D-3 describes the NMEA-0183 sentence set supported by various receivers and identifies the page number where you can find detailed information about each sentence. Some sentences are only supported when specific Trimble options are installed on the receiver. Sentences beginning with PTNL are Trimble proprietary sentences.

Table D-3 Supported NMEA-0183 Sentences

Sentence	Sentence Contents
ALM	GPS week number, SV health, and complete almanac data for one SV. One sentence per SV, up to a maximum of 32
GBS Sentence	GNSS Satellite Fault Detection
GGA Sentence	Time, position, and fix related data
GLL Sentence	Position fix, time of position fix, and status
GRS Sentence	GPS Range Residuals
GSA Sentence	GPS position fix mode, SVs used for navigation and DOP values
GST Sentence	GPS Pseudorange Noise Statistics
GSV Sentence	Number of SVs visible, PRN numbers, elevation, azimuth and SNR values
MSS Sentence	Signal strength, signal-to-noise ratio, beacon frequency, and beacon bit rate
RMC Sentence	UTC time, status, latitude, longitude, speed over ground (SOG), date, and magnetic variation of the position fix
VTG Sentence	Actual track made good and speed over ground
XTE Sentence	Cross-track error
ZDA Sentence	UTC time, day, month, and year, local zone number and local zone minutes.
PTNLAG001 Proprietary Sentence	66 character sentence available when TEXTA or TEXTB are selected as the port input protocol.
PTNLID Proprietary Sentence	Receiver machine ID, product ID, major and minor release numbers, and firmware release date.
PTNLDG Proprietary Sentence	Beacon channel strength, channel SNR, channel frequency, channel bit rate, channel number, channel tracking status, RTCM source, and channel performance indicator.
PTNL,GGK	Time, Position, Position Type and DOP Values
PTNLMS	Reference Station Number ID and the contents of the Special Message included in valid RTCM Type 16 records.

D.3 ALM Sentence

(GPS Almanac Data)

The ALM sentence identifies the GPS week, SV health, and contains the almanac for one satellite. The sentence structure is shown below:

```
$GPALM,1,1,03,698,00,6ae6,1d,779f,fdef,a10d
68,6469a6,7c1f62,5f5839,*43
```

Table D-4 identifies the ALM sentence fields.

Table D-4 ALM Sentence Fields

Field	Description
1	Total number of ALM sentences for this cycle
2	Sentence sequence number
3	SV PRN number, 01 to 32
4	GPS week number
5	SV health status
6	Eccentricity
7	Almanac reference time
8	Inclination angle
9	Rate of right ascension
10	Root of semi-major axis
11	Argument of perigee
12	Longitude of ascension node
13	Mean anomaly
14	A f0, clock parameter
15	A f1, clock parameter

D.4 GBS Sentence

(GNSS Satellite Fault Detection)

The GBS sentence is used to support Receiver Autonomous Integrity Monitoring (RAIM). The data structure is shown below:

```
$GBS,183059.30,0.0,0.0,0.0,0.0,0.0,0.0*6F
```

Table D-5 describes the GBS sentence fields.

Table D-5 GBS Sentence Fields

Field	Description
1	UTC time of the GGA or GNS fix associated with this sentence.
2	Expected error in latitude. [†]
3	Expected error in longitude. [†]
4	Expected error in altitude. [†]
5	ID number of most likely failed satellite.
6	Probability of missed detection for most likely failed satellite.
7	Estimate of bias, in meters, on most likely failed satellite.
8	Standard deviation of bias estimate.

[†] Expected error in meters due to bias with noise equals 0.



Note – Because the contents of this NMEA message do not change significantly during a 1-second interval, the receiver outputs this message at a maximum rate of 1 Hz.

D.5 GGA Sentence

(GPS Fix Data)

The GGA sentence contains the time, position, and fix related data. The sentence structure is shown below:

```
$GPGGA,151924,3723.454444,N,12202.269777,W,
2,09,1.9,-17.49,M,-25.67,M,1,0000*57
```

Table D-6 identifies the GGA sentence fields.

Table D-6 GGA Sentence Fields

Field	Description
1	UTC of position fix in HHMMSS.SS format
2	Latitude in DD MM,MMMM format (0-7 decimal places)
3	Direction of latitude N: North S: South
4	Longitude in DDD MM,MMM format (0-7 decimal places)
5	Direction of longitude: E: East W: West
6	GPS Quality indicator 0: fix not valid 1: GPS fix 2: DGPS fix
7	Number of SVs in use, 00-12
8	HDOP
9	Antenna height, MSL reference
10	'M' indicates that the altitude is in meters.
11	Geoidal separation
12	'M' indicates that the geoidal separation is in meters
13	Age of differential GPS data record, Type 1. Null when DGPS not used
14	Base station ID, 0000-1023

D.6 GLL Sentence

(Position Data)

The GLL sentence specifies the position fix, time of position fix, and status. The sentence structure is shown below:

```
$GPGLL,3723.4543,N,12202.2696,W,151933,A*3E
```

Table D-7 identifies the GLL sentence fields.

Table D-7 GLL Sentence Fields

Field	Description
1	Latitude in DD MM,MMMM format (0-7 decimal places)
2	Direction of latitude N: North S: South
3	Longitude in DDD MM,MMMM format (0-7 decimal places)
4	Direction of longitude E: East W: West
5	UTC of position in HHMMSS.SS format
6	Fixed text 'A' shows that data is valid
7	See RMC Sentence, page D-17, row 12.

D.7 GRS Sentence

(GPS Range Residuals)

The GRS sentence is used to support the Receiver Autonomous Integrity Monitoring (RAIM). The sentence structure is shown below:

```
$GPRGS,220320.0,0,-0.8,-0.2,-0.1,-  
0.2,0.8,0.6,,,,,,,,*55
```

Table D-8 describes the GRS sentence fields.

Table D-8 GRS Sentence Fields

Field	Description
1	UTC time of GGA position fix
2	Residuals 0: Residuals used to calculate position given in the matching GGA line 1: Residuals recomputed after the GGA position was computed
3-14	Range residuals for satellites used in the navigation solution, in meters



Note – Because the contents of this NMEA message do not change significantly during a 1-second interval, the receiver outputs this message at a maximum rate of 1 Hz.

D.8 GSA Sentence

(GPS DOP and Active Satellites)

The GPS sentence identifies the GPS position fix mode, the SVs used for navigation, and the DOP values. The sentence structure is shown below:

```
$GPGSA,A,3,19,28,14,18,27,22,31,29,,,,,1.7,
1.0,1.3*35
```

Table D-9 identifies the GSA sentence fields.

Table D-9 GSA Sentence Fields

Field	Description
1	Mode M: Manual, forced to operate in 2D or 3D A: Automatic, 3D/2D
2	Mode 1: Fix not available 2: 2D 3: 3D
3-14	ID's of SVs used in position fix (null for unused fields)
15	PDOP
16	HDOP
17	VDOP

D.9 GST Sentence

(GPS Pseudorange Noise Statistics)

The GST sentence is used to support Receiver Autonomous Integrity Monitoring (RAIM). The sentence structure is shown below:

```
$GPGST,220320.0,1.3,0.8,0.5,166.1,0.8,0.5,1.6,*4F
```

Table D-10 describes the GST sentence fields.

Table D-10 GST Sentence Fields

Field	Description
1	UTC time of GGA fix
2	RMS value of the standard deviation of the range inputs to the navigation process (range inputs include pseudoranges and DGPS corrections)
3	Standard deviation of semi-major axis of error ellipse, in meters
4	Standard deviation of semi-minor axis of error ellipse, in meters
5	Orientation of semi-major axis of error ellipse, in degrees from true north
6	Standard deviation of latitude error, in meters
7	Standard deviation of longitude error, in meters
8	Standard deviation of altitude error, in meters



Note – Because the contents of this NMEA message do not change significantly during a 1-second interval, the receiver outputs this message at a maximum rate of 1 Hz.

D.10 GSV Sentence

(GPS Satellites in View)

The GSV sentence identifies the number of SVs in view, the PRN numbers, elevation, azimuth and SNR values. The sentence structure is shown below:

```
$GPGSV,4,1,13,02,02,213,,03,-  
3,000,,11,00,121,,14,13,172,05*67
```

Table D-11 identifies the GSV sentence fields.

Table D-11 GSV Sentence Fields

Field	Description
1	Total number of sentences of this type in this cycle
2	Sentence number
3	Total number of SVs visible
4	SV PRN number
5	Elevation in degrees, 90½ maximum
6	Azimuth, degrees from true north, 000½ to 359½
7	SNR, 00-99 dB (null when not tracking)
8-11	Information about second SV, same format as fields 4-7
12-15	Information about third SV, same format as fields 4-7
16-19	Information about fourth SV, same format as fields 4-7



Note – Because the contents of this NMEA message do not change significantly during a 1-second interval, the receiver outputs this message at a maximum rate of 1 Hz.

D.11 MSS Sentence

(Beacon Receiver Signal Status)

The MSS sentence identifies the status of the beacon signal, including the beacon signal strength, beacon signal-to-noise ratio (SNR), beacon frequency, and beacon bit rate. The sentence structure is shown below:

```
$GPMSS,52.5,23.7,287.0,100*4C
```

Table D-12 describes the MSS sentence fields.

Table D-12 MSS Sentence Fields

Field	Description
1	Signal Strength (SS), dB ref: 1 μ V/m
2	Signal-to-Noise Ratio (SNR), dB
3	Beacon Frequency, 283.5 to 325.0 kHz
4	Beacon Bit Rate (25, 50, 100, 200), bits per second
5	Channel Number



Note – Because the contents of this NMEA message do not change significantly during a 1-second interval, the receiver outputs this message at a maximum rate of 1 Hz.

D.12 RMC Sentence

(Recommended Minimum Specific GPS Data)

The RMC sentence identifies the UTC time, status, latitude, longitude, speed over ground (SOG), date, and magnetic variation of the position fix. The sentence structure is shown below:

```
$GPRMC,184804.00,A,3723.476543,N,12202.2397
45,W,000.0,0.0,051196,15.6,E*7C
```

Table D-13 describes the RMC sentence fields.

Table D-13 RMC Sentence Fields

Field	Description
1	Time: UTC time of the position fix in hhmmss.ss format
2	Status A: Valid V: Navigation Receiver Warning (V is output whenever the receiver suspects something is wrong)
3	Latitude coordinate (the number of decimal places, 0–7, is programmable and determined by the numeric precision selected in TSIP Talker for a RMC sentence)
4	Latitude direction: N = North, S = South
5	Longitude coordinate (the number of decimal places, 0–7, is programmable and determined by the numeric precision selected in TSIP Talker for a RMC sentence)
6	Longitude direction W: West E: East
7	Speed Over Ground (SOG) in knots (0–3 decimal places)
8	Track Made Good, True, in degrees
9	Date in dd/mm/yy format
10	Magnetic Variation in degrees

Table D-13 RMC Sentence Fields (Continued)

Field	Description
11	Direction of magnetic variation E: Easterly variation from True course (subtracts from True course) W: Westerly variation from True course (adds to True course)
12	Mode Indication A: Autonomous D: Differential N: Data not valid

D.13 VTG Sentence

(Course Over Ground and Ground Speed)

The VTG sentence identifies the actual track made good and speed over ground. The sentence structure is shown below:

```
$GPVTG,0,T,,0.00,N,0.00,K*33
```

Table D-14 identifies the VTG sentence fields.

Table D-14 VTG Sentence Fields

Field	Description
1	Track made good
2	Fixed text 'T' shows that track made good is relative to true north
3	Not used
4	Not used
5	Speed over ground in knots (0–3 decimal places)
6	Fixed text 'N' shows that speed over ground is in knots
7	Speed over ground in kilometers/hour (0–3 decimal places)
8	Fixed text 'K' shows that speed over ground is in kilometers/hour



Note – Because the contents of this NMEA message do not change significantly during a 1-second interval, the receiver outputs this message at a maximum rate of 1 Hz.

D.14 XTE Sentence

(Cross-Track Error)

The XTE sentence reports the vessel's cross-track error. The sentence structure is shown below:

```
$GPXTE,A,A,0.050,L,N*5E
```

Table D-15 describes the XTE sentence fields.

Table D-15 XTE Sentence Fields

Field	Description
1	A: Valid (fixed)
2	A: Valid (fixed)
3	Cross-track Error, in nautical miles
4	Direction to Steer L: Left R: Right
5	N:Nautical mile units



Note – For the NT300D, steering direction in XTE is opposite of the direction shown on the display. The display shows which side on the track you are on

D.15 ZDA Sentence

(Time and Date)

The ZDA sentence identifies UTC time, day, month, and year, local zone number and local zone minutes. The sentence structure is shown below:

```
$GPZDA,184830.15,05,11,1996,00,00*66
```

Table D-16 identifies the ZDA sentence fields.

Table D-16 ZDA Sentence Fields

Field	Description
1	UTC time
2	Day
3	Month
4	Year
5	Local Zone Number (– for East Longitude)
6	Local Zone Minutes



Note – Because the contents of this NMEA message do not change significantly during a 1-second interval, the receiver outputs this message at a maximum rate of 1 Hz.

D.16 PTNLAG001 Proprietary Sentence

(Text Message)

The PTNLAG001 sentence is a proprietary Trimble NMEA sentence which sets the 66 character sentence string output when TEXTA or TEXTB are selected as port input options. The sentence structure is shown below:

```
$PTNLAG001,XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX*XX
```

Table D-17 identifies the PTNLAG001 sentence fields.

Table D-17 PTNLAG001 Sentence Fields

Field	Description
1	66 character text string received when TEXTA or TEXTB is enabled as a port input option

D.17 PTNLID Proprietary Sentence

(Trimble Receiver Identity)

The PTNLID sentence is a Trimble proprietary sentence for identifying the receiver's machine ID, product ID, major and minor release numbers, and firmware release date. The sentence structure is shown below:

```
$PTNLID,097,01,XXX,XXX,DD/MM/YY*XX
```

Table D-18 identifies the PTNLID sentence fields.

Table D-18 PTNLID Sentence Fields

Field	Description
1	Machine ID
2	Product ID
3	Major firmware release number
4	Minor firmware release number
5	Firmware release date, in DD/MM/YY format

The PTNLID sentence is enabled using TSIP. If enabled, the sentence is output every 30 seconds.

D.18 PTNLDG Proprietary Sentence

(Trimble DGPS Receiver Status)

The PTNLDG sentence is a Trimble proprietary sentence for identifying the DGPS receiver channel strength, channel SNR, channel frequency, channel bit rate, channel number, channel tracking status, RTCM source, and channel performance indicator for either beacon DGPS or satellite DGPS. The sentence structure is shown below:

```
$PTNLDG,XXX.X,XX.X,XXXXXXXX.X,XXXXX,XX,X,X,X  
XX*XX
```

The PTNLDG sentence fields are defined in free format with the maximum number of characters in the field indicated in above (i.e. 25 bps displayed as xxx,25,xxx instead of xxx,00025,xxx). Additionally, if a channel is disabled, the channel fields may be null fields (commas only). If more than one channel is available, the sentence should be repeated for each channel. Table D-19 identifies the sentence fields.

Table D-19 PTNLDG Sentence Fields

Field	Description
1	Channel signal strength, in 1 dBuV/m. For beacon, this is the electromagnetic field intensity level. For satellite, this is the ADC input voltage level.
2	Channel signal to noise (SNR) level, in dB
3	Channel frequency, in kHz
4	Channel bit rate, in bits per second (bps)
5	Channel number, 0-99
6	Channel tracking status 0: Channel idle 1: Wideband FFT search 2: Searching for signal 3: Channel has acquired signal 4: Channel has locked on signal 5: Channel disabled
7	Specified channel is used as RTCM source 0: Not used 1: Used
8	Channel tracking performance indicator. For beacon, this is the number of errors in the last 255 words. For satellite, this is the time since last sync, in tenths of seconds ranging from 0-255.

This message can be enabled using TSIP. If enabled, it is output at the NMEA report rate.



Note – Because the contents of this NMEA message do not change significantly during a 1-second interval, the receiver outputs this message at a maximum rate of 1 Hz.

D.19 PTNL,GGK Sentence

(Time, Position, Position Type and DOP Values)

The PTNL,GGK message string is shown below:

```
$PTNL,GGK,172814.00,071296,3723.46587704,N,
12202.26957864,W,3,06,1.7,EHT-6.777,M*48
```

Table D-20 describes the PTNL,GGK sentence fields.

Table D-20 PTNL,GGK Sentence Fields

Field	Description
1	UTC of position fix, in hhmmss.ss format
2	UTC Date of position, in mmddyy format
3	Latitude, in degrees and decimal minutes (e.g. dddmm.mmmmmmm)
4	Direction of latitude: N: North S: South
5	Longitude, in degrees and decimal minutes (e.g. dddmm.mmmmmmm)
6	Direction of Longitude: E: East W: West
7	GPS Quality indicator: 0: Fix not available or invalid 1: Autonomous GPS fix 4: Differential, code phase only solution (DGPS)
8	Number of satellites used in GPS solution
9	DOP of fix
10	Ellipsoidal height of fix (antenna height above ellipsoid)
11	M: Ellipsoidal height is measured in meters

D.20 PTNLSM Proprietary Sentence

(RTCM Special Message)

The PTNLSM sentence is a Trimble proprietary sentence for identifying the Reference Station ID and the ASCII Text message included in a RTCM Type 16 Special Message. The PTNLSM message is generated anytime a RTCM stream receives a valid Type 16 Special Message. The sentence structure is shown below:

```
$PTNLSM,0022,This is a message,*.XX
```

Table D-21 describes the PTNLSM sentence fields.

Table D-21 PTNLSM Sentence Fields

Field	Description
1	Reference Station ID number, ranging from 0 to 1023. Leading zeros must be added to fill 4-digit field.
2	ASCII text message sentence contained within the Type 16 RTCM message.

E Flash Loader 100

Flash Loader 100 makes updating the Trimble AgGPS receiver firmware quick and trouble-free. You can also use this utility to review your receiver's configuration, add purchased receiver enhancement options, and, if technical assistance is needed, collect troubleshooting information.



Tip – Flash Loader 100 and the latest AgGPS firmware can be downloaded from Trimble's FTP site. The address is [FTP://FTP.TRIMBLE.COM](ftp://ftp.trimble.com). You can also access the FTP site from the Trimble World Wide Web site ([WWW.TRIMBLE.COM/SUPPORT.HTM](http://www.trimble.com/support.htm)).


E.1 Connecting to the Flash Loader Software

To install the Flash Loader software, do the following:


1. Turn on the computer and run Windows 95 or Windows NT.
2. Select *Run* from the **Start** menu.
3. In the *Run* window, type the following:

C:\<Flash Loader file name>

If you are using a different drive or folder, the pathname may be different.

4. Click .
5. Follow the instructions provided by the Flash Loader 100 Setup program.

To update receiver firmware, do the following:

1. Using the Standard Data/Power Cable (P/N 30945), connect the AgGPS receiver to the PC's serial port (usually COM1 or COM2).
2. From **Start**, select the Flash Loader 100 software.
3. Click .

The Flash Loader 100 software detects the receiver and automatically selects the correct port. A message box indicates on which port the receiver is found.

If Flash Loader 100 is unable to detect the receiver, try the following:


- Make sure that the receiver is connected to an available power source.
- Switch the cable from receiver port A to port B (or vice versa).
- Check all cable connections between the receiver and PC.

Click  again.


E.2 Using Flash Loader 100

The main window in the Flash Loader 100 software displays an options checklist. Once the receiver has been successfully detected, select one or more of the available options. Table E-1 describes each option.

Table E-1 Flash Loader 100 Options

Options	Description
Update Receiver with Password	Enables the <i>Enter Password</i> screen to appear. Enter Trimble supplied passwords to activate receiver enhancements such as Fast Rate, Everest, and the Base Station option.
Download Configuration	Enables two radio button options that determine how the downloaded information is processed. Read into file: Configuration data is written to a specified text file. Review on-screen: The receiver's configuration settings are detailed on the PC computer screen.
Upload New Firmware	When selecting the Upload New Firmware checkbox for the first time, a file dialog appears. In the file dialog: Navigate to the directory where the new receiver firmware file is stored. Only files that have the TNR (Trimble Navigation ROM) extension are displayed. Select the appropriate file and click  . Flash Loader 100 checks the firmware file to make sure that it is valid. If the file is found invalid, a warning message appears. The Upload New Firmware checkbox is automatically deselected.
Read Error Log	Writes the error log data, stored in the receiver, to a file for use by Trimble technical support personnel. Use the dialog to change the filename or storage folder.

E.3 Running Flash Loader 100

After checking the appropriate options, click .

Once the process is complete, a message box indicates a successful completion.

If a warning message appears, disconnect the receiver and try again. If the problem persists, contact Trimble Technical Support.

F Activating a Satellite DGPS Service

This appendix provides step-by-step instructions for activating both OmniSTAR and Racal-LandStar DGPS services.

OmniSTAR Activation

OmniSTAR Activation Guide -- AgGPS 132 Only

START HERE





Figure F-1 OmniSTAR Activation Guide

Racal Activation

START HERE



IMPORTANT INFORMATION

Racal-LandStar User Code: _____

Satellite Footprint: _____

Racal-LandStar Contact Numbers	
Location	Number
North America	1-888-434-7757
Australasia	1-800-802-573
Europe	(44)-1493-857011
Central and Southern Africa	++27-21-704-1600
Middle East and Western CIS	++9712-554817

Racal-LandStar Activation Guide -- AgGPS 132 Only

Figure F-2 Racal-LandStar Activation Guide

Index

Numerics

1 pps output 1-14

A

about this manual xix

accuracy

 DGPS 1-4

 factors affecting

 base station receiver 1-6

 elevation mask 1-5

 environmental factors

 multipath 1-6

 multipath 1-6

 number of visible

 satellites 1-4

 PDOP 1-5

 signal to noise ratio

 (SNR) 1-5

 GPS

 measuring 1-7

activating a satellite DGPS service F-1

 OmniSTAR F-3

 Racal F-5

Adjusted Area screen 4-4

AgField pack 1-12

AgGPS 132 receiver

 back panel 1-13

 components 2-2

 configuring 6-1

 connections 1-13

 input (ASCII, TSIP,

 RTCM) 1-14

 output (RTCM, TSIP,

 NMEA, 1 pps) 1-14

 enhancements 2-3

 front panel

 using 3-1

 installation 2-1

 guidelines 2-5

 mounting 2-6

 overview 1-1, 7-1

 physical characteristics A-1, B-1

 standard features 1-10

ALM message A-3

ALM sentence D-8

almanac D-8

Alternate Beacon screen 5-12

Altitude screen 5-5

antenna

 cable

 routing, connecting 2-8

 mounting 2-6

 electrical interference 2-7

 physical characteristics A-2

application options 1-12

 AgField pack 1-12

parallel swathing 1-12
Area Calculation screen 4-3
audience xix

B

base station configuration 6-29
beacon
 3rd order interception A-3
 channel selectivity A-3
 channel spacing A-3
 dynamic range A-3
 frequency 1-7
Beacon DGPS status screens 5-10
 alternate beacon 5-12
 beacon status 5-11
 DGPS age 5-14
 DGPS data source 5-13
Beacon Mode screen 6-11
Beacon Status screen 5-11

C

cable
 CASE AFS Power/Data 2-12
 data interface C-3, C-4
 dual data interface C-5
 GreenStar data 2-13
 Power/Data RTCM/NMEA 2-16
 RDS 2-17
 standard data/power 2-10
 Windows CE cable 2-18
 Windows CE with cigarette power
 adapter 2-18
cautions xxiv
components list 2-2

Configuration Lockout screen 3-13
configuration screens
 Language 3-13
 Configuration Lockout 3-13
 Contrast 3-11
 Language 3-14
configuring Port A parameters 6-19
configuring the AgGPS 132 receiver 6-1
 using keypad 6-2
connecting external devices 2-9
 optional Ag Leader power/data
 cable 2-15
 optional CASE AFS power/data
 cable 2-12
 optional GreenStar data
 cable 2-13
 optional power/data RTCM/
 NMEA cable 2-16
 optional RDS cable 2-17
 optional Windows CE cable 2-18
 optional Windows CE with
 cigarette power adapter
 cable 2-18
 standard data/power cable 2-10
Contrast screen 3-11
copyrights ii

D

Date and GPS Week screen 5-24
datums
 NAD-83 1-7
 WGS-84 1-7
DGPS accuracy 1-4
DGPS Age screen 5-14, 5-19
DGPS Configuration screens 6-8
 Beacon Mode 6-11

- DGPS Correction Age 6-10
- DGPS Mode 6-9
- DGPS Source 6-10
- Easy Satellite DGPS
 - Configuration 6-15
- Manual Beacon Frequencies 6-14
- OmniSTAR Activation 6-17
- Racal Solution 6-18
- Satellite Baud 6-17
- Satellite Frequency 6-16
- DGPS Correction Age screen 6-10
- DGPS Data Source screen 5-13, 5-18
- DGPS Mode screen 6-9
- DGPS Source screen 6-10
- differential base station 1-11
- Differential GPS (DGPS)
 - positioning 1-3
- disclaimer of warranty iii
- document conventions xxiii
- DOPs screen 5-9
- Dynamic Mode screen 6-8

E

- Easy Satellite DGPS Configuration
 - screen 6-15
- elevation mask 1-5
- enhancements 2-3
- Everest technology 1-11
- external devices
 - connecting 2-9

F

- fast rate 1-11
- File Transfer Protocol (FTP) site xxi

- Firmware Version and Release Date
 - screen 5-26
- Flash Loader 132 E-1
 - connecting to software E-2
 - running E-4
 - using E-3
- frequencies
 - beacon 1-7
- front panel
 - using 3-1
- ftp.trimble.com xxi

G

- getting started 3-1
- GGA message A-3
- GGA sentence D-10
- GLL message A-3
- GLL sentence D-11
- GP Talker ID D-5
- GPS Configuration screens 6-3
 - Dynamic Mode 6-8
 - GPS mode 6-4
 - PDOP settings 6-6
 - PV Filter and Position Rate 6-7
 - Restore Defaults 6-3
 - System Masks 6-5
- GPS error
 - sources of 1-3
- GPS Mode screen 6-4
- GPS status screens 5-3
 - altitude 5-5
 - DOPs 5-9
 - location 5-4
 - satellite information 5-7
 - velocity 5-6
- GRS output sentence D-12

GSA message A-3
GSA sentence D-13, D-15
GST output sentence D-14
GSV message A-3
GSV sentence D-15
guidelines

installation 2-5

H

Home screen 3-5
beacon and satellite mode 3-6

I

II Talker ID D-5
Incident Report screen 5-29
input
ASCII, RTCM, TSIP 1-14
inspecting shipment 2-1
installation
guidelines 2-5
choosing a location 2-5
considering environmental
conditions 2-5

K

keypad actions 3-4

L

Language screen 3-13, 3-14
LC Talker ID D-5
LG Talker ID D-5
limitation of liability iii

limited warranty
firmware iv
hardware iv
software iv
Location screen 5-4

M

Manual Beacon Frequencies
screen 6-14
manual organization xx
measuring GPS accuracy 1-7
receiving DGPS
beacon 1-7
receiving satellite DGPS (AgGPS
132 only) 1-9
mounting
antenna 2-6
receiver 2-6
MSS message A-3
multipath 1-3, 1-6

N

NAD 83 1-7
NMEA-0183
latitude and longitude values D-5
messages
GGA A-3
GLL A-3
GSA A-3
GSV A-3
MSS A-3
RMC A-3
VTG A-3
ZDA A-3

- other values D-6
- sentence
 - ALM D-8
 - checksum values D-4
 - description D-1
 - field formats D-4
 - fields D-4
 - GGA D-10
 - GLL D-11
 - GSA D-2, D-13, D-15
 - GSV D-15
 - null fields D-4
 - PTNLAG001 D-22
 - PTNLDG D-24
 - PTNLID D-23
 - RMC D-17
 - sample structure D-2
 - structure D-1
 - summary D-6
 - summary of supported sentences D-6
 - symbols and delimiters D-3
 - VTG D-15, D-19
 - ZDA D-1, D-21
- Talker ID Codes
 - GP D-5
 - II D-5
 - LC D-5
 - LG D-5
- time values D-5
- notes xxiv
- number of visible satellites 1-4

O

- OmniSTAR 1-9
- OmniSTAR Activation screen 6-17

- OmniSTAR Info screen 5-21
- organization
 - of manual xx
- other information xxi
 - File Transfer Protocol (FTP) site xxi
 - World Wide Web (WWW) site xxi
- output
 - 1 pps 1-14
 - RTCM, TSIP, NMEA, 1 pps 1-14
- overview 1-1
 - AgGPS 132 receiver 1-1, 7-1

P

- parallel swathing 1-12
- Path Length screen 4-5
- PDOP 1-5
- PDOP Settings screen 6-6
- performance characteristics
 - GPS channels A-3
- Perimeter screen 4-5
- physical characteristics
 - AgGPS 132 receiver A-1, B-1
 - combined antenna A-2
- pin-out diagrams
 - dual data interface cable C-5
 - dual interface cable C-3, C-4
 - general description C-1
 - overview C-1
 - Port A C-2
 - Port B C-2
 - tables C-1

- Port A
 - NMEA 2
 - configuration 6-23
 - parameters
 - configuring 6-19
- Port parameters
 - configuring
 - input 6-20
 - output 6-21
- position dilution of precision 1-5
- PTNLAG001 sentence D-22
- PTNLDG sentence D-24, D-25, D-27
- PTNLID sentence D-23
- PV Filter and Position Rate screen 6-7

R

- Racal Solution screen 6-18
- Racal-LandStar 1-9
- Racal-LandStar Service Info
 - screen 5-20
- RAIM
 - GAST output sentence D-14
 - GRS output sentence D-12
- reader comment form xxiii
- receiver status screens
 - Receiver Options 5-27
- receiver
 - connections 1-13
 - defaults B-1
 - enhancement 1-11, 2-3
 - Differential Base Station 1-11
 - Everest technology 1-11
 - Fast Rate 1-11
- Receiver Options screen 5-27
- Receiver Serial Number screen 5-25
- Receiver Status screens 5-23

- Date and GPS Week 5-24
- Firmware Version and Release
 - Date 5-26
- Incident Report 5-29
- Receiver Serial Number 5-25
- System Voltages 5-28
- Time 5-23
- receiving DGPS
 - beacon 1-7
 - satellite 1-9
- related information xxi
 - update notes xxi
- reporting shipping problems 2-4
- Restore Defaults screen 6-3
- revision notice iii
- RMC message A-3
- RMC sentence D-17
- routing, connecting
 - antenna cable 2-8

S

- Satellite Baud screen 6-17
- Satellite DGPS Status screens 5-15
 - DGPS Age 5-19
 - DGPS Data Source 5-18
 - OmniSTAR Info 5-21
 - Racal-LandStar Service Info 5-20
 - satellite differential status 5-16
 - Service ID and Initialization
 - Vector 5-22
 - service provider ID 5-17
- Satellite Differential Status screen 5-16
- Satellite Frequency screen 6-16
- Satellite Information screen 5-7
- scope xix
- screens

- configuration
 - base station 6-29
 - base location 6-30
 - base mode 6-34
 - Port A output 6-35
 - Port B output 6-35
 - NMEA 1 6-22
 - Port A 6-19
 - Port A input 6-20
 - Port A output 6-21
- GPS status 5-3
- Home 3-5
- status
 - DGPS
 - beacon 5-9
 - viewing 3-3
- utility 4-2
- Segment Length screen 4-5
- selective availability (S/A) 1-3, 1-8
- Service ID and Initialization Vector screen 5-22
- Service Provider ID screen 5-17
- shipping
 - reporting problems 2-4
- signal-to-noise ratio (SNR) 1-5
- sources of electrical interference 2-7
- sources of GPS error 1-3
 - atmospheric conditions 1-3
 - multipath 1-3
 - receiver (electronic) noise 1-3
 - selective availability 1-3
- specifications A-1
- standard features 1-10
- System Masks screen 6-5
- System Voltages screen 5-28

T

- TAC xxii
- Talker ID D-5
- technical assistance xxii
- Technical Assistance Center
 - TAC xxii
- Time screen 5-23
- tips xxiv
- trademarks iii
- troubleshooting 7-1
 - beacon GPS works in some places
 - but not others 7-4
 - checking for antenna cable failure 7-4
 - choosing an antenna location 7-4
 - determining if beacon is operable 7-5
 - increasing GPS accuracy 7-1
 - interfacing receiver with other RTCM sources 7-6
 - intermittent GPS loss 7-3
 - losing beacon signal at night 7-5
 - losing configuration settings when receiver is powered off 7-7
 - overview 7-1
 - power lines and strong magnetic fields 7-3
 - reducing engine noise 7-5
 - restoring receiver to factory defaults 7-8
 - receiver front bulges out 7-8
 - satellite DGPS works in some places but not others 7-6
 - using optional TSIP Talker software 7-6
 - verifying RTCM source is

- outputting messages 7-7
- verifying unit is outputting NMEA messages 7-7
- troubleshooting guides
 - beacon 7-15
 - GPS reception 7-11
 - GPS reception - using a yield monitor 7-13
 - OmniSTAR 7-17
 - Racal-LandStar 7-19
 - system hardware and power check 7-9

U

- update notes xxi
- using the front panel 3-1
- UTC
 - GRS sentence D-12
 - GST sentence D-14
- utility screens 4-2
 - adjusted area 4-4
 - area calculation 4-3
 - path length 4-5
 - perimeter 4-5
 - segment length 4-5

V

- Velocity screen 5-6
- View menu 6-1
- viewing screen status 3-3
- VTG message A-3
- VTG sentence D-15, D-19

W

- warnings xxiv
- WGS-84 1-7
- World Wide Web (WWW) site xxi
- www.trimble.com xxi
- www.trimble.com/support/support.htm xxi

X

- XTE
 - output sentence D-20

Z

- ZDA message A-3
- ZDA sentence D-1, D-2, D-20, D-21

Reader Comment Form

AgGPS 124/132 Operation Manual
P/N: 38747-00

February 1999
Revision A

We appreciate your comments and suggestions for improving this publication. Contributors of particularly helpful evaluations will receive a thank-you gift.

I use the following Trimble product _____
for _____

Please circle a response for each of the statements below:

1 = Strongly Agree 2 = Agree 3 = Neutral 4 = Disagree 5 = Strongly Disagree

The manual is well organized	1	2	3	4	5
I can find the information I want.	1	2	3	4	5
The information in the manual is accurate.	1	2	3	4	5
I can easily understand the instructions.	1	2	3	4	5
The manual contains enough examples.	1	2	3	4	5
The examples are appropriate and helpful.	1	2	3	4	5
The layout and format are attractive and useful.	1	2	3	4	5
The illustrations are clear and helpful.	1	2	3	4	5
The manual is:	too long	just right	too short		

Please answer the following questions:

Which sections do you use the most? _____

What do you like best about the manual? _____

What do you like least about the manual? _____

Optional

Name _____

Company _____

Address _____

Telephone _____ Fax _____

Please mail to the local office listed on the back cover or to Trimble Navigation Limited, Precision Agricultural Systems, 645 North Mary Avenue, Post Office Box 3642, Sunnyvale, CA 94088-3642. All comments and suggestions become the property of Trimble Navigation Limited.

