

INSTRUCTIONS FOR ELECTRONIC READING

If the left motor has been equipped with an electronic readout, in addition to our conventional optic system.

To obtain a gravity reading electrically the gravity meter assembly the orientation knob turned counter clockwise to 0, and the dial turned in the proper direction to cancel out the scale error.

The inexperienced operator should first read the instructions on the station reading the gravity meter by the opening of this manual and familiarize himself with the gravity meter.

When the left motor does not show the left hand scale as observed in the eyepiece. The galvanometer will indicate 2 or 3 eyepiece divisions each side of zero. The distance between one eyepiece division and one full scale division when on or near the reading line is about one to one.

After a brief practice period the operator should be able to obtain gravity readings quite rapidly and accurately with the electronic readout.

In the event of a component failure the gravity meter can be used with the standard optic system.


FIELD SERVICE AND ELECTRONIC REPAIRS

1) When polarity is correct when connecting meter to 12 volt battery.


2) Check the following:

- A) Gravity meter and its shaft with gravity meter connected to 12 volt battery.
- B) Gravity meter in proper adjustment.
- C) Zero position. (no zero proper reading line is being used.)
- D) Adjust zero zero to reading line (Center of galvo). This is the potentiometer labeled "zero adjust". Turning the zero pot clockwise causes the galvo needle to move to the right.
- E) Turn dial clockwise one tenth milligal (10 small dial units). Turn potentiometer of galvo needle. Turn sensitivity adjust pot until galvo reads one division for one tenth milligal dial change.
- F) Clockwise adjustment will increase sensitivity.
- G) Repeat steps (4) and (5) several times and tune if necessary.
- H) Check for proper V.D. electronic reader. If it is showing with the meter be checked for broken wires, low voltage or diaphragm conditions. If failure does occur, the gravity meter will probably need to be returned to the manufacturer for repair.

A fuse should be added in the power line to the electronics to prevent damage. If correct polarity is not observed when connecting gravity meter to battery. However, it is a good safety practice to always observe polarity.



SIMPLIFIED DIAGRAM OF
CONDENSER READ-OUT CIRCUIT



Special Instructions for the Variable Damped
Model G Gravity Meter

The variable damped Model G gravity meter is identical to the standard Model G gravity meter, but has variable damping features.

The upper and lower sectional side view of the variable damped design is shown in the following pages.

To adjust the damping the aluminum cover plate or nylon screw on the end of the upper section is removed. (It will probably be easier to reach this screw if the meter is placed on its side.)

When the drive slot of the lower adjusting screw will then be visible. The lower adjusting screw spring keeps this screw in the down position. The upper screw in the slot push inward and engage the slot of the upper adjusting screw. For maximum damping the screw is turned counter clockwise about 1/2 turn from the revolution. A very minimum of torque will be required to turn the adjusting screw and a positive stop will be felt. A lower screw is removed the coil spring should force the lower adjusting screw out.

The damping is approximately that of a standard Model G meter in the down position.

The damping is approximately 10% of a fully 50% damped meter in the up position.

The meter is designed to be contained under maximum damping in the up position. The beam positioner switch is a normally closed contact which is closed by the gravity meter. To move the beam positioner of the switch on the right is pressed and down. The switch is normally open. The switch will also operate when the meter is in the up position.

The meter is designed to be powered by the external power supply.

The meter is designed to be used in the up position. It is important to keep in mind that the meter is designed to overcome approximately 75 milligrams of spring force. It will be necessary to use the spring tension adjustment (see the manual) in conjunction with the beam positioner to initiate the meter in the up position. It may be a good practice to gently tap the meter so that if the beam is slightly sticking on a stop, an excessive amount of initial force can be provided.


For the meter to operate properly it is important that the lower adjusting screw is forced out and away from the upper adjusting screw. The sectional view of damper design.

UPPER SCREW PROVIDES MAX. DAMPING


The 10000 and 100000 Model C Gravity Meters and the accessories that are normally supplied with the gravity meter are shown in Figures 1 thru 4. Model C Gravity Meters have a range of over 7000 Milligals, a reading accuracy of 0.01% and a drift rate of less than 1 mgal. per month.

The 10000 and 100000 Gravity Meters are sealed to eliminate any possibility of atmospheric pressure. As a safety precaution, they are normally pressure compensated. The sensor is completely de-aerated and protected within a stainless shield.

The gravity meter, carrying case and battery weigh about 19 pounds. The battery charger and levelling disc weigh an additional 9 pounds.



MODEL G GRAVITY METER, CONCAVE LEVELING DISC
AND ALUMINUM CARRYING-SHIPING CASE




ALUMINUM CARRYING-SHIPING CASE

ALUMINUM CARRYING-SHIPING CASE WITH METER

FIG. 3

INTERNAL-ADAPTER


ALLEN METHOD




BATTERY CHARGER
CABLE

FIG. 4

AUXILIARY BATTERY
CABLE





PRINCIPLE OF OPERATION

Principle of Operation of LaCoste and Romberg Gravity Meter

A simplified diagram of the basic LaCoste and Romberg gravity meter is shown in the diagram. The gravity response system consists of a weight on the end of a horizontal beam supported by a zero-length spring as shown in the diagram. The chest is mounted on a roller float, thus eliminating any friction in the moving parts. Hence the gravity response system is completely suspended by springs. It will withstand nearly any shock that will not damage the housing which supports it.

The lever system and measuring screw shown in the diagram are accurately linear throughout their entire range. Calibration factors depend only on the quality of the measuring screw and the lever system, not upon any type of wish auxiliary springs. For this reason, the calibration factors of LaCoste and Romberg meters do not change appreciably with time. This eliminates any need for frequent checks of calibration.

Operating Instructions

The gravity meter is usually shipped unthermostated. Since the temperature of the LaCrosse and Becking instrument is thermostatically controlled, the first step is to bring the instrument to its operating temperature (shown on the cover page of this manual). The meter should automatically thermostat at this temperature. Connect the power cord from the meter to:

1. The battery eliminator unit (see section "Battery Eliminator-Removal of Battery Unit") OR
2. The battery supplied with the gravity meter OR
3. Any 12 volt battery source.

The nickel-cadmium battery normally supplied with the meter has a capacity of 7 ampere hours. The red tag tied to the battery indicates the state of charge. Usually the battery is shipped in a discharged state and must be fully charged before connecting the meter from it. See section on battery before charging.

A cable, referred to as an auxiliary battery cable, is supplied for connecting the meter to a 12-volt d.c. power source other than the battery supplied with the meter. Caution must be observed when connecting this cable.

The gravity meter should be allowed to stabilize at its operating temperature minimum of two hours prior to use. This is necessary if reliable gravity readings are to be obtained.

The following is a general procedure for obtaining a gravity reading:

1. Place the meter on the concave levelling disc furnished with the meter. (If conditions permit, the operator may prefer not to use the disc.)
2. Turn on the Heide level, line levels and optical system by means of the switch located on top of the gravity meter.
3. Level the meter using the levelling screws located beneath the meter. Some models in larger cases are leveled by means of the level on top of the gravity meter.
4. Release the beam of the gravity meter by turning the arrestment knob counter clockwise to its limit.
5. The position of the beam can be determined by observing the shadow, or crosshair, in the telescope. This crosshair is actually the image of a very fine wire attached to the beam. This image is magnified and then viewed through the reticule, or scale, for a reading reference. The total width of the crosshair is usually about 14 to 16 scale divisions. The magnification is usually 10x. The image of the crosshair is usually inverted. See illustration.

When the level is used, a level vial is marked, and the vial is placed in the level. The level is then used to level the meter.

- (3) The downscale side of the crosshair is brought to the reading line (as given on the meter) by turning the measuring screw.

To move the crosshair upscale, the measuring screw is turned clockwise, and to move the crosshair downscale the measuring screw is turned counterclockwise. The reading line should be approached by turning the measuring screw in the same direction each time to avoid any possible backlash. (Always reflect the levels before the final reading is taken.)

- (4) Obtain the meter reading from the counter and the dial. The last digit on the counter and the numbers on the dial should correspond to the same number of units. The dial is further divided into tenths of a unit and can be read from its

center. The numbers on the dial are read from the center of the dial. (Note that the number on the dial is read from the left side of the dial.) This can be accomplished by loosening the dial cover and turning the dial to such an extent that the point of agreement with the reading on the dial is aligned with the center of the dial.

COUNTER-DIAL Gravity Reading to Milligals

To obtain the value in Milligals from the reading of the counter-dial dial (see Table I). In Table I, the value of gravity in milligals is given for each 100 units of the counter (the last digit on the counter indicates tenths). By using the scale, and the corresponding factor, the value of gravity for any reading of the counter can be obtained in the following manner:

1. Note the counter reading (Example: 2654.3).
2. Note the counter interval (Example: .36). The reading is then 2654.36.
3. From Table I, the "Counter Reading" column use the counter reading (2654.36) but less than it. For this example, the counter reading could be 2600. Observe the "Value in Milligals" for counter reading of 2600 is 2731.10 Mgls.
4. Obtain the difference in the original Counter-dial reading and the counter reading chosen from Table I in Step 3.

$$2654.36 - 2600 = 54.36$$
5. Multiply this difference (54.36) by the Interval factor given in the table for a counter reading of 2600.

$$54.36 \times 1.05239 = 57.21$$
6. Add the product obtained in Step 5 to the Milligal value observed in Step 3. The sum thus obtained is the milligal value for the gravity station.

$$2731.10 + 57.21 = 2788.31$$

Example Table I

COUNTER READING	VALUE IN MILLIGALS	FACTORS FOR INTERVAL
2500	2621.98	1.05237
	2731.10	1.05239
	2839.34	1.05242


1

LONG LEVEL

ADJUSTING SCREW

SHORT LEVEL

ADJUSTING SCREW



ADJUSTMENT KNOB

LIGHT SWITCH

THERMOMETER

TEMPERATURE

CONTROL KNOB

METER

USUI

MODEL

1.2.1. Checking the Gravity Meter.

The gravity meter is a very reliable and accurate instrument. It is probable that it is probably correct to within 0.01 mgals under normal use.

The following procedure is advised.

(1) Check the displacement sensitivity (adjustment of the level level, so that the level that is parallel to the longest diameter of the top of the level).

(2) Turn the level.

(3) Turn the level.

(4) Turn the level.

(5) Turn the level of crosshair.

(6) Turn the level (measuring screw) to locate upper and lower stops (on the limits of crosshair).

(7) Turn the level by means of measuring screw about one revolution above lower stop.

(8) Turn measuring screw dial clockwise one revolution, which is ten units on the counter, or approximately 1 Milligal.

(9) Observe the number of units the crosshair moves in the eyepiece.

(10) The correct displacement sensitivity should be approximately one eyepiece division for one counter unit.

If the displacement sensitivity check shows a sensitivity of approximately one eyepiece division for 10 counter units then a long level adjustment is necessary.

If the displacement sensitivity is low it means a slight loss in reading accuracy. (The crosshair responds to a dial change but the amount is less. Consequently, it is more difficult to detect crosshair movement.)

Conversely, if the displacement sensitivity is high, more accurate readings are obtainable but the response is slower. Actually on certain specialized designs, the displacement sensitivity has been doubled to increase reading accuracy. The amount of increase in sensitivity, however, the meter becomes unstable and cannot be used.

2. During the Displacement Sensitivity (Long Level)

Adjustment to both the level and cross level may be made externally through holes in the black phenolic top of the gravity meter located near the end of each level. These access holes are covered by two small black anodized plates. Loosen the small screw holding the plate and rotate the plate to give access to an Allen-head cap screw directly below. After determining the proper level position for the gravity meter as described below, adjust the level by turning the cap screw with the Allen wrench furnished to bring the level bubble into a centered position. After a final check, replace the cover plates.

On some models it may be necessary to remove the phenolic top from the gravity meter for more level adjustments.

With the case open, remove the dial and top. Remove the eye-piece from the telescope tube and insert it in the telescope tube adapter supplied with the instrument which is also supplied for making adjustment to the level needle.

Adjustment of the level needle should be made in small increments. A movement of one or two divisions is all that will be required.

When the level needle is adjusted, the level bubble will not be centered. The level bubble is centered by leveling the instrument. A leveling screw (away from optical center) is used to level the instrument. A leveling screw with a "T" handle to determine the level position. The leveling screw is inserted, turned, either in the direction of the level position. The level bubble should then be centered. (An optical level is usually used to determine the level position. An optical level is usually used independently of the gravity meter. Several attempts may be made to level the instrument.)

The level position is the level position when the level bubble is centered and adjusted.

- (1) If the sensitivity is high, the gravity meter is tilted so the level bubble with one leveling screw is raised. (Bubble not in the center of the scale.) Then the same procedure outlined in (2) is followed.
- (2) Leveling - correct reading line.
- (3) Leveling - carefully
- (4) Set micrometer on reading line as specified for the meter. If this is not known, choose a position approximately midway between the steps.
- (5) Keeping the cross-level in the level position, tilt the long level end division, first one direction and then in the other and record the cyclople reading. Repeat several times to be sure of the reading.



... If the eyepiece moves upscale approximately 1 division, then the chosen reading line is correct.

If the eyepiece moves up appreciably more when the meter is tilted, the level is too low. If the crosshair goes down for the tilt, the chosen reading line is too low.

- (C) If the correct reading line was not chosen in Step (B), then the eyepiece should be shifted one eyepiece division with the dial counter up or down depending on results of Step (E) and the tilting procedure repeated.

... It should be checked whenever the long level (displacement sensitivity) is checked.

... After tilting the meter off-level wait approximately 30 seconds for the beam to level.

... Level is Level

The correct setting of the cross levels is the setting which gives the minimum tilt. It can be checked by moving the cross level one division off-level, first in one direction and then in the other. If the cross level setting is correct, the crosshair should move upscale approximately an equal amount for each tilt. For use the long level is in the level position each time the meter is read. If the cross level is out of adjustment proceed as follows:

- (A) Level meter so that the cross level is off center approximately half of a division in the direction which gave the low eyepiece reading in the above experiment.

Using the level wrench supplied with meter, adjust the cross level screw to the center position and repeat the reading procedure described above.

On those models where it is necessary to remove the plastic top, the adjustment is made by adjusting the nuts on the level vital mounting flange with the level wrench supplied. A very small nut rotation is usually all that is required. When the top is replaced and the dial is installed remember to phase the numbers on the dial with the corresponding last numbers on the counter.

It has been assumed that only minor adjustments were necessary. If large adjustments are needed into proper adjustment. In this case the steps 1 through 4 are repeated. However, if one or both of the levels is off several numeric divisions, after adjustment of each level the other level should be rechecked.

Temperature Control Circuitry

All components associated with the temperature control system are solid state. The temperature-sensing thermistor bridge operates an amplifier and power transistor which deliver current to the heating element. The components are of high quality with a long life expectancy. A circuit diagram is included in this manual.

If the meter fails to heat properly the trouble is most likely to be caused by a broken wire in the power cable, a bad plug connection, improper battery voltage (polarity also must be observed), or bad connections to the battery.

If the trouble is not found in these areas, the instrument will probably have to be returned to our laboratory.

The operator should familiarize himself with the best operating temperature for the meter and be alert for detectable changes in the temperature. Except in extreme weather conditions when the outside temperature equals the stem of the thermometer, there should be no visible change in the thermometer reading.

7. Reading Light and Level Lights

The reading lamp in the Model C gravity meter is a #130 12-volt aircraft lamp. The level lights, directly beneath the level vials, are #337 28-volt aircraft lamps. When the level lamps are operating on less than one half of their rated voltage, they will have an extremely long life.

Although the reading lamp operates at 12 volts, it too has a very long life. (Normally 2 spare reading lamps are furnished). Access to this lamp is obtained by removing the aluminum disc on the side of the meter. To remove the reading lamp loosen the screw securing the copper contact strip. The lamp is easily removed from the bakelite tube. It will be necessary to adjust the lamp for optimum brightness and clarity. Be sure the screw holding the lamp is well secured after replacing or adjusting the reading lamp.

NOTE: As a matter of good field practice the level lights and reading lamp should be turned off between readings to prolong lamp life, reduce drift, and reduce power consumption and excessive heat around the level vials.

7. The Battery

Detailed charging instructions and other pertinent information on applying the specific battery supplied with this meter is included in this manual.

8. General Information

(A) Temperature control

About two hours are required to heat the meter to its operating temperature. Since the meter must be stabilized at this temperature for a least two additional hours prior to obtaining gravity readings, we recommend the meter be maintained at its operating temperature constantly. This is good field practice even though the meter is used intermittently. To keep the meter at its operating temperatures when it is not in use, either the battery eliminator or the battery charger may be used. If a battery charger is used, leave the gravity meter connected to the battery and set the battery charger for about .2 ampere charging current. For idle periods of more than 24 hours

NOTE: The accuracy of the meter is seriously affected by storing the meter off for

(14) Adjustments or clamping mechanism. The level of the gravity meter should be clamped between readings to avoid any variation in spring length which might result in errors due to hysteresis, or change of position of the movable system. Although much improvement has been made over the years, occasionally the beam (crosshair) will stick on the bottom, top or sometimes both stops. Usually a gentle tap on the case will free the beam. Although this can be somewhat annoying, the accuracy is not normally affected. Generally, sticking does not occur until the meter has been in use for several years. If necessary to return the meter to our laboratory for cleaning of the stops to eliminate the sticking.

(15) Frequently customers ask how often a meter should be returned to the laboratory for a routine cleaning and check out. Probably the best criteria for this is the results that are being obtained. If good gravity ties are being obtained and no major problems are obvious, then there is no need to return the meter to the laboratory for a check up.

When meters are sent in for servicing we suggest that the battery charger, and all cables be included. Usually about a week to ten days is required for a general cleaning and check out.

(16) Gravity meter unstable. On a few occasions the long level on a gravity meter has gotten out of adjustment enough so that the meter becomes unstable. When this condition exists it is difficult or impossible to balance the beam on the reading line. The crosshair can not be controlled with the measuring screw. The operator can duplicate this condition by tilting the meter two or three bubble divisions in the sensitive direction (See Section - Setting the Displacement Sensitivity) and observing; the correction of course is to adjust the long level as outlined earlier.

Battery Eliminator - Battery Charger Unit

Function of Battery Eliminator-Battery Charger Unit.

The Battery Eliminator-Battery Charger Unit is designed to operate on line voltage of 110 volts to 250 volts, 50-60 Hz, AC only.

The Battery Eliminator-Battery Charger Unit serves two purposes:

1. To provide a source of power when the gravity meter is stopped for a period of time.

2. To provide a means for recharging of battery.

1. Battery Eliminator-Charger Unit

1. Battery Eliminator

Put the main line switch in Eliminator position. (Switch up). Turn voltage selector switch counterclockwise to the F1 position. In this position the unit is capable of receiving a maximum of 250 VAC. Connect power plug to line voltage. Rotate voltage selector switch clockwise until the AC Voltmeter indicates about 110 volts.

Disconnect the power cable from the gravity meter to the Eliminator Plug on the Eliminator-Charger Unit. The gravity meter is now being energized even though the battery is removed from the circuit. The voltmeter will indicate the amount of current being consumed.

2. Battery Charging

When the battery has charged from the operating mode to approximately 1.25 volts per cell, the battery is ready for recharging.

Remove the battery from the Eliminator-Charger Unit. Connect the battery to the charging circuit to avoid damage to the battery. (See Figure 1.)

Connect the positive (+) terminal of the Charger to the positive (+) terminal of the battery. Connect the negative (-) terminal of the Charger to the negative (-) terminal of the battery.

Turn the main line switch to the Eliminator-Charger position. The AC Voltmeter should indicate approximately 110 volts. The battery should be operated with the AC voltmeter set at voltage 110. The battery should never be operated with a line voltage over 110 volts. Turn the Range Adjusting potentiometer to the maximum value recommended by the manufacturer.

When the battery has charged longer than normally recommended, the battery may be overcharged, which might result in the battery being damaged.

The Eliminator-Charger Unit can be used to charge one or two batteries. The charging rate can be used for low or high rates. This is determined by the manufacturer's recommendations. The charging rate of each battery.

Although the charger has the capability of charging 3 batteries simultaneously, the manufacturer does not recommend this procedure unless absolutely necessary. This is because minor differences in the internal resistance of cells after cycling may result in extreme variations in their status of charge, causing an overcharge in some cells and polarity reversal in others.

If two batteries are being charged simultaneously, each of the charging rate or the charging time must be doubled. This is because when the batteries are being charged in parallel and the ammeter indicates only the total current flow in the charger circuit. If either of the batteries are removed from the charger individually, then the charging rate or charging time of the remaining battery should be adjusted accordingly.

See instructions on battery charging in this manual.

The battery may be charged with the gravity meter connected to the battery, / Id 0.2 - 0.3 amps to the charging rate or compensate for the average current being drawn by the meter circuitry.

Mounting the Battery Eliminator / Battery Charger Unit.

This unit is designed and constructed so that with reasonable care a long service life can be expected. All components are used well within their safe working limits.

The charger section is protected by a 4-amp circuit breaker and is generally trouble free. If the circuit breaker is engaged and the charger does not operate, check for broken wires in the charger leads or between the battery terminals.

In addition to the circuit breaker a fuse has been placed in the power lead. A spare fuse is attached inside and handy.

Finally, this unit is supplied with a 3-wire power cable. The

Instructions for use of the Gravity Meter for Galvanic Cell

The Gravity Meter is used to measure the density of the electrolyte in a battery. It is used on the following:

1. To determine the state of charge of a battery. The density of the electrolyte in a fully charged battery is about 1.280. The density of the electrolyte in a fully discharged battery is about 1.200.

2. To determine the state of charge of a battery. The density of the electrolyte in a fully charged battery is about 1.280. The density of the electrolyte in a fully discharged battery is about 1.200. The density of the electrolyte in a partially charged battery is about 1.240. The density of the electrolyte in a partially discharged battery is about 1.220.

3. To determine the state of charge of a battery. The density of the electrolyte in a fully charged battery is about 1.280. The density of the electrolyte in a fully discharged battery is about 1.200. The density of the electrolyte in a partially charged battery is about 1.240. The density of the electrolyte in a partially discharged battery is about 1.220.

4. To determine the state of charge of a battery. The density of the electrolyte in a fully charged battery is about 1.280. The density of the electrolyte in a fully discharged battery is about 1.200. The density of the electrolyte in a partially charged battery is about 1.240. The density of the electrolyte in a partially discharged battery is about 1.220.

UNCLASSIFIED

UNCLASSIFIED

Battery Type AGN-300

Drawing No. 00013900000000000000

Capacity 4 Ah at the 5 hour rate



Number of Series Connected Cells 10

Nominal Voltage 13.5

Fully Charged 13.8 Volts or more

Fully Discharged 12.5 Volts or less

GRAPH DATA



AGN-300 is a Nickel-Cadmium (Ni-Cd) battery. It is designed for use in a wide range of environments. The battery is maintenance-free and has a long life span. It is suitable for use in applications where a reliable power source is required. The battery is available in a variety of sizes and capacities. It is a popular choice for use in military and aerospace applications. The battery is also used in a wide range of industrial and commercial applications. It is a reliable and durable power source that can be used in a wide range of environments.

Perhaps the most frequently asked question concerning the Nickel Cadmium battery is how to determine the state of charge.

The true state of charge of a sealed Ni-Cad battery is very difficult to determine. Specific gravity readings do not give reliable results. If the time ~~elapsed~~ or the amount discharged since the battery was last charged is unknown, it is recommended the battery be given a charge prior to use as outlined above. That is, treated as a discharged battery.

If the battery has been only partially discharged and the approximate temperature of the cells is known, the battery may be restored to a fully charged condition by multiplying the number of ampere-hours discharged instead of the number of ampere-hours.

Overcharging or overcharge is NOT recommended. The elevated battery temperature and overcharging will be a contributing factor in reducing battery life. Battery temperature should be maintained in a fully charged state at room temperature. The battery should be recharged on the 100% basis.


Sealed batteries may be discharged at quite low rates. However, they should not be discharged below the end voltage indicated on the label. Deep discharge is the result of a cell reversal. Cell reversal can be caused by reversal of the polarity of the charger or by overdischarge of the battery. While this may not be detrimental to the battery if it happens only occasionally, deep discharging should be avoided. Normally cell reversal is corrected by recharging at the standard rate.

As with most storage batteries self-discharge will occur. The rate is very temperature sensitive. At 75°F a loss of up to 20% of the charge will occur in two weeks, at 125°F this loss will occur in two or three days, while at 0°F it will occur in one year. Note that this is a loss in state of charge, recoverable by recharging, and a permanent loss of capacity.

The Fusion 16V6-AM battery requires no usual battery maintenance. It is filled with electrolyte and sealed at the factory.

- 1. Keep terminals clean and tight.
- 2. Never attempt to add electrolyte or distilled water.
- 3. Do not place intermediate circuit taps on the battery.

See Also & Remarks: For Model C and Model D Gravity Meters



Differential Output: Do Not Ground Either

Capacitance Resistor Card

* ZO and ZO are connected externally to OV if meters

Electrostatic Positioning Switches

Electrostatic Positioning Switches

Cheater Module

Heater (Approx. 15W)

Heat Control Module

Bimetallic Thermostat

T = Thermostat 10K at 100 C

Level Straps

Key

Key

126-218 Ampphenol

100K-B-200-20

100K-B-200-20

TABLE 1

TABLES FOR ADDRESS & BONDAGE, INC. MODEL C CITY JUNO 10-584

	VALUE IN ADDRESS	FACTOR FOR ADDRESS	COUNTY CODE	VALUE IN BONDAGE	FACTOR FOR BONDAGE
000	000.00	1.02727	1000	3001.00	1.02706
100	103.73	1.02711	1700	3001.70	1.02710
200	205.44	1.02696	3000	3001.91	1.02717
300	306.13	1.02686	3900	4006.37	1.02716
400	410.82	1.02679	4000	4105.15	1.02718
500	514.50	1.02676	4100	4211.44	1.02719
600	616.18	1.02672	4200	4315.14	1.02721
700	718.85	1.02671	4300	4417.10	1.02722
800	821.32	1.02671	4400	4521.42	1.02723
900	924.10	1.02673	4500	4625.24	1.02723
1000	1026.86	1.02675	4600	4729.07	1.02723
1100	1129.54	1.02677	4700	4833.09	1.02717
1200	1232.21	1.02680	4800	4938.70	1.02710
1300	1334.89	1.02682	4900	5034.53	1.02707
1400	1437.58	1.02686	5000	5137.32	1.02703
1500	1540.26	1.02690	5100	5241.32	1.02705
1600	1642.95	1.02693	5200	5347.32	1.02709
1700	1745.65	1.02696	5300	5449.31	1.02703
1800	1848.33	1.02703	5400	5549.07	1.02776
1900	1951.03	1.02703	5500	5649.07	1.02763
2000	2053.74	1.02713	5600	5754.00	1.02751
2100	2156.47	1.02720	5700	5856.78	1.02738
2200	2259.19	1.02724	5800	5959.32	1.02727
2300	2361.91	1.02731	5900	6062.34	1.02706
2400	2464.64	1.02736	6000	6164.94	1.02704
2500	2567.33	1.02741	6100	6267.63	1.02701
2600	2670.12	1.02748	6200	6370.29	1.02717
2700	2772.87	1.02755	6300	6471.93	1.02711
2800	2875.62	1.02763	6400	6575.54	1.02785
2900	2978.39	1.02770	6500	6678.12	1.02717
3000	3081.15	1.02775	6600	6780.88	1.02729
3100	3183.93	1.02781	6700	6883.21	1.02701
3200	3286.71	1.02788	6800	6985.71	1.02711
3300	3389.50	1.02793	6900	7088.16	1.02442
3400	3492.29	1.02798	7000	7190.62	

Value in address & bondage approximately 1000