

GDP-32^{II} Manual

Table of Contents

	<u>LABELS</u>		<u>LABELS</u>
1. Introduction	<u>Introduction</u>	8. RPIP	<u>RPIP</u>
1.1 Warranty.....	2	8.1 Introduction.....	2
1.2 Product Information	3	8.2 Program Operation.....	4
2. Description Of The GDP-32^{II} Receiver	<u>Description</u>	8.3 Data Collection	8
2.1 Overview	2	8.4 Field Configurations	14
2.2 Specifications	3	9. TDIP	<u>TDIP</u>
2.3 GDP-32 ^{II} Case	9	9.1 Introduction.....	2
3. System Start Up	<u>Start Up</u>	9.2 Program Operation.....	3
3.1 Initial Receiver Check.....	2	9.3 Data Collection	8
3.2 Powering Up The GDP-32 ^{II}	4	9.4 Sample Data Blocks.....	13
3.3 Shutting Down The GDP-32 ^{II}	5	9.5 Algorithms	15
3.4 Charging Batteries.....	6	9.6 Time Domain Window Timing Information.....	17
4. Quick Start	<u>Quick Start</u>	9.7 Field Configurations	18
4.1 Introduction	2	10. CR / HACSAMT	<u>CR</u>
4.2 Receiver Start-Up	3	10.1 Introduction.....	2
4.3 Enter Survey Parameters	5	10.2 CR Program Operation.....	3
4.4 Calibration	7	10.3 Gathering Data	10
4.5 System Check.....	11	10.4 A Note On Phase.....	16
4.6 Synchronization.....	14	10.5 A Note On Scaling.....	16
4.7 Acquire Field Data	16	10.6 3-Point Decoupling.....	17
4.8 Check Data In The Data Cache	17	10.7 Sample Data Blocks.....	18
4.9 Data Transfer To A Computer.....	18	10.8 Notes On Field Configurations	20
5. Accessing Programs	<u>Access</u>	10.9 Sample Menus For 'LABROX' Option	21
5.1 The Main Program Menu	2	10.10 Sample Menus For 'HACSAMT' Option	24
5.2 Field Survey Program Screens	6	10.11 Field Configurations	26
5.3 Scaling.....	16	11. CSAMT	<u>CSAMT</u>
6. Receiver Setup	<u>Setup</u>	11.1 Introduction.....	2
6.1 Calibration	2	11.2 Fixed Function Keys	3
6.2 Synchronizing Timing Circuits	15	11.3 CSAMT Program Operation	4
6.3 Measuring Contact Resistance	30	11.4 Gathering Data	11
6.4 Setting The Powerline Notch Filter.....	31	11.5 A Note On Variable A-Spacing	16
6.5 Gains.....	32	11.6 A Note On Phase.....	16
6.6 Bits Of Resolution	46	11.7 A Note On Scaling.....	16
7. Handling Data	<u>Data</u>	11.8 Restrictions	17
7.1 Monitoring Analog Signals	2	11.9 Sample Data Blocks.....	21
7.2 Viewing Data.....	3	11.10 Notes On Field Configurations	22
7.3 Accessing Caches.....	7	11.11 Magnetic Coil Connections.....	22
7.4 Initializing Caches.....	10	11.12 Field Configurations	23
7.5 Configuring Ports	12	11.13 Method To Field-Check Magnetic Sensors.....	25
7.6 Outputting Data	14		
7.7 Input Antenna Calibration Data.....	17		
7.8 Up-Loading Program Files Via The LAN	19		

	LABELS
12. TEM	<u>TEM</u>
12.1 Introduction	2
12.2 Fixed Function Keys	3
12.3 TEM Program Operation	4
12.4 Powerline Noise Rejection	12
12.5 Gathering Data	13
12.6 A Note On Scaling	17
12.7 Sample Rates And Antialias Filter Delays	18
12.8 TEM Window Centers For Zero Delay	19
12.9 TEM Window Centers And Widths	20
12.10 Sample Data Blocks	21
12.11 Field Configurations And Magnetic Antennas	22
12.12 Ramp-Off Time, GGT Transmitters	23
12.13 TEM Receiver / Transmitter Arrays	24
12.14 Example: First Window Time Determination	25
12.15 The NanoTEM System	26
12.16 NanoTEM Hookup Directions	27
12.17 NanoTEM Window Centers, 1.6us Sample Period	28
12.18 NanoTEM Window Centers, 1.2us Sample Period	29
12.19 NanoTEM Window Centers, Shallow Applications	30
12.20 NanoTEM Sample Data	32
12.21 NanoTEM Field Setup	33
12.22 Field Configurations	34
12.23 Equal-Interval Mode TEM	39
12.24 Method To Field-Check Magnetic Sensors	41
13. MT / AMT	<u>AMT</u>
13.1 Introduction	2
13.2 Fixed Function Keys	3
13.3 MT/AMT Program Operation	4
13.4 Gathering Data	13
13.5 A Note On Variable A-Spacing	17
13.6 A Note On Phase	17
13.7 A Note On Scaling	17
13.8 Restrictions	18
13.9 Sample Field Data	19
13.10 Notes On Field Configurations	23
13.11 Cascade Decimation Overview	24
13.12 Data Dump Utility	26
13.13 Time Series File Format	27
13.14 Time Schedule	29
13.15 Field Configurations	34
13.16 Method To Field-Check Magnetic Sensors	38
14. Plotting Routines	<u>Plot</u>
14.1 Introduction	2
14.2 Summary Of Plots For Different Data Types	4
14.3 Introduction	5
14.4 Error Messages	6

	LABELS
15. Mathematical Algorithms	<u>Mathematics</u>
15.1 Standard Error Of The Mean (SEM)	2
15.2 3-Point Decoupling	3
15.3 A Note On Resistivity Calculations	4
15.4 Resistivity Calculations	5
15.5 Useful CSAMT Equations	12
15.6 Useful TEM Equations	13
16. GDP-32^{II} Design	<u>Design</u>
16.1 Basic Design Characteristics	2
16.2 Receiver Layout	4
16.3 AMD 586 Card-PC MPU Board	8
16.4 Bd187 Front Panel Board	10
16.5 Bd183 Analog Board	10
16.6 The Calibration And Timing Board	18
16.7 The Battery Compartment	25
16.8 The Crystal Oscillator	26
17. Maintenance And Trouble-Shooting	<u>Maintenance</u>
17.1 Board Functions And Diagnostics	2
17.2 Handling Boards	15
17.3 Digital Board Problems	18
17.4 Analog Board Problems	20
17.5 Battery And Power Problems	23
17.6 Synchronization Problems	28
17.7 Cold Weather Operation	32
17.8 Pinouts For Connectors	33
17.9 Error Messages	40
18. GDP-32^{II} User's Notes	<u>User's Notes</u>
18.1 Use Of The Attenuator	2
18.2 Recalibrate When Replacing Analog Cards	2
18.3 Connecting Peripherals To The GDP-32 ^{II}	3
18.4 Always Measure Contact Resistance – CRES	3
18.5 Transmitter Controller Specifications	4
18.6 Transmitter Control Interface	5
18.7 Resistance Of Standard Gauge Wire	6
18.8 Setup Instructions For Loadbank LB2500	7
18.9 Antenna Designations	8
18.10 Serial Port Data Transfer Using HyperTerminal	9